

# TMDXEVM6670L EVM

## Technical Reference Manual

### Version 2.1

Literature Number: SPRUH59

Revised November 2011

**ADVANTECH**



#### **Document Copyright**

#### **Publication Title:**

TMDXEVM6670L Technical Reference Manual All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under copyright laws.

## **EVALUATION BOARD / KIT / MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMER**

### **Not for Diagnostic Use: For Feasibility Evaluation Only in Laboratory/Development Environments**

The EVM may not be used for diagnostic purposes.

This EVM is intended solely for evaluation and development purposes. It is not intended for use and may not be used as all, or part of an end equipment product.

This EVM should be used solely by qualified engineers and technicians who are familiar with the risks associated with handling electrical and mechanical components, systems and subsystems.

### **Your Obligations and Responsibilities**

Please consult the EVM documentation, including but not limited to any user guides, setup guides or getting started guides, and other warnings prior to using the EVM. Any use of the EVM outside of the specified operating range may cause danger to users and/or produce unintended results, inaccurate operation, and permanent damage to the EVM and associated electronics. You acknowledge and agree that:

You are responsible for compliance with all applicable Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, UL, CSA, VDE, CE, RoHS and WEEE,) that relate to your use (and that of your employees, contractors or designees) of the EVM for evaluation, testing and other purposes.

You are responsible for the safety of you and your employees and contractors when using or handling the EVM. Further, you are responsible for ensuring that any contacts or interfaces between the EVM and any human body are designed to be safe and to avoid the risk of electrical shock.

You will defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of, or in connection with any use of the EVM that is not in accordance with the terms of this agreement. This obligation shall apply whether Claims arise under the law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

### **Warning**



The EVM board may get very hot during use. Specifically, the DSP, its heat sink and power supply circuits all heat up during operation. This will not harm the EVM. Use care when touching the unit when operating or allow it to cool after use before handling. If unit is operated in an environment that limits free air flow, a fan may be needed.

# Preface

## About this Document

This document is a Technical Reference Manual for the TMS320C6670 Evaluation Module (TMDXEVM6670) designed and developed by Advantech Limited for Texas Instruments, Inc.

## Notational Conventions

This document uses the following conventions:

Program listings, program examples, and interactive displays are shown in a mono spaced font. Examples use bold for emphasis, and interactive displays use bold to distinguish commands that you enter from items that the system displays (such as prompts, command output, error messages, etc.).

Square brackets ( [ and ] ) identify an optional parameter. If you use an optional parameter, you specify the information within the brackets. Unless the square brackets are in a bold typeface, do not enter the brackets themselves.

Underlined, italicized non-bold text in a command is used to mark place holder text that should be replaced by the appropriate value for the user's configuration.

## Trademarks

The Texas Instruments logo and Texas Instruments are registered trademarks of Texas Instruments. Trademarks of Texas Instruments include: TI, XDS, Code Composer, Code Composer Studio, Probe Point, Code Explorer, DSP / BIOS, RTDX, Online DSP Lab, TMS320, TMS320C54x, TMS320C55x, TMS320C62x, TMS320C64x, TMS320C67x, TMS320C5000, and TMS320C6000.



MS-DOS, Windows, Windows XP, and Windows NT are trademarks of Microsoft Corporation.

UNIX is a registered trademark of The Open Group in the United States and other countries.

All other brand, product names, and service names are trademarks or registered trademarks of their respective companies or organizations.

## Document Revision History

Release	Chapter	Description of Change
1.0	All	The first release for Beta1 and Beta2 EVMs
2.0	All	The second release for Rev 2.0 production EVM
2.1	All	The third release for Rev 3.0 production EVM

## Acronyms

Acronym	Description
AMC or <i>AdvancedMC</i>	Advanced Mezzanine Card
AIF2	Antenna Interface 2
CCS	Code Composer Studio
DDR3	Double Data Rate 3 Interface
DSP	Digital Signal Processor
DTE	Data Terminal Equipment
EEPROM	Electrically Erasable Programmable Read Only Memory
EMAC	Ethernet Media Access Controller
EMIF	External Memory Interface
EVM	Evaluation Module
FPGA	Field Programmable Gate Array
I2C	Inter Integrated Circuit
IPMB	Intelligent Platform Management Bus
IPMI	Intelligent Platform Management Interface
JTAG	Joint Test Action Group
LED	Light Emitting Diode
MCH	MicroTCA Carrier Hub
MTCA or <i>MicroTCA</i>	Micro Telecommunication Computing Architecture
MMC	Module Management Controller
PICMG®	PCI Industrial Computer Manufacturers Group
RFU	Reserved for Future Use
SDRAM	Synchronous Dynamic Random Access Memory
SERDES	Serializer-Deserializer
SGMII	Serial Gigabit Media Independent Interface
SRIO	Serial RapidIO
UART	Universal Asynchronous Receiver/Transmitter
USB	Universal Serial Bus
XDS560v2	Texas Instruments' System Trace Emulator

# Table of Contents

<b>1. Overview</b> .....	11
1.1 Key Features.....	11
1.2 Functional Overview .....	12
1.3 Basic Operation.....	12
1.4 Boot Mode and Boot Configuration Switch Setting.....	13
1.5 Power Supply .....	14
<b>2. Introduction to the TMDXEV6670L board</b> .....	15
2.1 Memory Map .....	15
2.2 EVM Boot Mode and Boot Configuration Switch Settings .....	19
2.3 JTAG - Emulation Overview.....	19
2.4 Clock Domains.....	20
2.5 Non-Volatile Memories (SEEPROM / SPI NOR Flash / NAND flash).....	21
2.6 FPGA Functions .....	22
2.7 Gigabit Ethernet Connections.....	23
2.8 Serial RapidIO (SRIO) Interface .....	24
2.9 DDR3 External Memory Interface.....	24
2.10 HyperLink interface.....	25
2.11 PCI express interface.....	26
2.12 Antenna Interface (AIF2).....	26
2.13 UART Interface .....	27
2.14 Module Management Controller (MMC) for IPMI .....	28
2.15 Expansion Headers.....	28
<b>3. TMDXEV6670L Board Physical Specifications</b> .....	29
3.1 Board Layout.....	29
3.2 Connector Index.....	30
3.2.1 560V2_PWR1, XDS560v2 Mezzanine Power Connector.....	31
3.2.2 AMC1, AMC Edge Connector .....	31
3.2.3 COM1, UART 3-Pin Connector .....	33
3.2.4 COM_SEL1, UART Route Select Connector .....	33
3.2.5 DC_IN1, DC Power Input Jack Connector.....	34
3.2.6 EMU1, TI 60-Pin DSP JTAG Connector.....	34
3.2.7 FAN1, FAN Connector.....	35
3.2.8 HyperLink1, HyperLink Connector .....	36
3.2.9 LAN1, Ethernet Connector .....	37
3.2.10 PMBUS1, PMBUS Connector for Smart-Reflex Control.....	37

3.2.11 TAP_FPGA1, FPGA JTAG Connector (For Factory Use Only).....	38
3.2.12 SBW_MMC1, MSP430 SpyBiWire Connector (For Factory Use Only) .....	39
3.2.13 TEST_PH1, Expansion Header (SPI, GPIO, Timer I/O, I <sup>2</sup> C, and UART) .....	39
3.2.14 USB1, Mini-USB Connector .....	40
<b>3.3 DIP and Pushbutton Switches .....</b>	<b>41</b>
3.3.1 RST_FULL1, Full Reset .....	41
3.3.2 RST_COLD1, Cold Reset.....	41
3.3.3 RST_WARM1, Warm Reset.....	41
3.3.4 SW3, SW4, SW5 and SW6 DSP Boot Configurations.....	41
3.3.5 SW9, DSP PCIE Enable / User Defined and DSP_DSPCLKSEL / FPGA_PACLKSEL Switch Configuration .....	43
<b>3.4 Test Points.....</b>	<b>44</b>
<b>3.5 System LEDs.....</b>	<b>45</b>
<b>4. System Power Requirements .....</b>	<b>47</b>
4.1 Power Requirements .....	47
4.2 Power Supply Distribution .....	50
4.3 The Power Supply Boot Sequence .....	54
<b>5. TMDXEVM6670L FPGA FUNCTIONAL DESCRIPTION .....</b>	<b>58</b>
5.1 FPGA overview.....	<b>58</b>
5.2 FPGA signals description.....	<b>59</b>
5.3 Sequence of operation .....	<b>65</b>
5.3.1 Power-on Sequence .....	65
5.3.2 Power Off Sequence.....	68
5.3.3 Boot Configuration Timing.....	69
5.3.4 Boot Configuration Forced in I2C Boot .....	70
5.4 Reset definition.....	<b>70</b>
5.4.1 Reset Behavior .....	70
5.4.2 Reset Switches and Triggers .....	70
5.5 SPI protocol .....	<b>72</b>
5.5.1 The FPGA-DSP SPI Protocol .....	72
5.5.2 The FPGA- CDCE62005 / CDCE62002 (Clock Generator) SPI Protocol.....	74
5.5.3 The FPGA- programming CDCE62005 / 62002 by the DSP .....	74
5.5.4 CDCE62005 / 62002 programming sequences on the FPGA .....	77
5.5.5 CDCE62005 / 62002 default value on the EVM .....	77
5.6 FPGA Configuration Registers .....	<b>78</b>
5.6.1 FPGA Configuration Registers Summary .....	79
5.6.2 FPGA Configuration Registers Descriptions .....	80

## List of Figures

Figure 1.1: Block Diagram of TMDXEVM6670L EVM .....	12
Figure 1.2: TMDXEVM6670L EVM Layout.....	13
Figure 2.1: TMDXEVM6670L EVM JTAG emulation .....	20
Figure 2.2: TMDXEVM6670L EVM Clock Domains.....	21
Figure 2.3: TMDXEVM6670L EVM NAND flash connections .....	22
Figure 2.4: TMDXEVM6670L EVM FPGA Connections.....	23
Figure 2.5: TMDXEVM6670L EVM Ethernet Routing.....	23
Figure 2.6: TMDXEVM6670L EVM SRIO Port Connections .....	24
Figure 2.7: TMDXEVM6670L EVM SDRAM .....	25
Figure 2.8: TMDXEVM6670L EVM HyperLink connections.....	25
Figure 2.9: TMDXEVM6670L EVM PCIE Port Connections.....	26
Figure 2.10: TMDXEVM6670L EVM AIF Port Connections.....	27
Figure 2.11: TMDXEVM6670L EVM UART Connections.....	27
Figure 2.12: TMDXEVM6670L EVM MMC Connections for IPMI.....	28
Figure 3.1: TMDXEVM6670L EVM Board Assembly Layout – TOP view.....	29
Figure 3.2: TMDXEVM6670L EVM Board layout – Bottom view .....	30
Figure 3.3: COM_SEL1 Jumper setting.....	34
Figure 3.4: The HyperLink Connector .....	36
Figure 3.5: TAP_FPGA1 function diagram.....	38
Figure 3.6: SW3, SW4, SW5, and SW6 default settings .....	42
Figure 3.7: SW9 default settings .....	43
Figure 3.8: TMDXEVM6670L test points on top side .....	44
Figure 3.9: TMDXEVM6670L test points on the bottom side .....	44
Figure 3.10: TMDXEVM6670L EVM Board LEDs .....	46
Figure 4.1: All the AMC power supply on TMDXEVM6670L EVM .....	50
Figure 4.2: The CVDD and VCC1V0 (CVDD1) power design on TMDXEVM6670L EVM.....	52
Figure 4.3: The VCC3_AUX power design on TMDXEVM6670L EVM .....	52
Figure 4.4: The VCC1V5 power design on TMDXEVM6670L EVM.....	53
Figure 4.5: The VCC5 power design on TMDXEVM6670L EVM .....	53
Figure 4.6: Initial Power-on Sequence Timing Diagram .....	56
Figure 4.7: Power Down Sequence Timing Diagram .....	57
Figure: 5-1 Power-on Reset Boot Configuration Timing.....	69
Figure: 5-2 Reset-Full Switch/Trigger Boot Configuration Timing .....	69
Figure 5-3: The SPI access form the TMS320C6670 to the FPGA (WRITE / high level).....	72
Figure 5-4: The SPI access form the TMS320C6670 to the FPGA (WRITE) .....	73



Figure 5-5: The SPI access form the TMS320C6670 to the FPGA (READ / high level) .....	73
Figure 5-6: The SPI access form the TMS320C6670 to the FPGA (READ) .....	73
Figure 5-7: The SPI access form the FPGA to the CDCE62005 (WRITE).....	74
Figure 5-8: The SPI access form the FPGA to the CDCE62005 (READ).....	74

## List of Tables

Table 2.1: TMS320C6670 Memory Map .....	16
Table 2.2: TMDXEVM6670L EVM NAND flash connections.....	22
Table 3.1: TMDXEVM6670L EVM Board Connectors.....	30
Table 3.2: XDS560v2 Power Connector pin out .....	31
Table 3.3: AMC Edge Connector.....	31
Table 3.4: UART Connector pin out.....	33
Table 3.5: UART Path Select Connector pin out.....	34
Table 3.6: TI 60-pin DSP JTAG Connector pin out.....	35
Table 3.7: FAN1 Connector pin out .....	36
Table 3.8: The HyperLink Connector .....	36
Table 3.9: Ethernet Connector pin out.....	37
Table 3.10: PMBUS1 Pin out .....	37
Table 3.11: FPGA JTAG Connector pin out .....	38
Table 3.12: MSP430 SpyBiWire Connector pin out .....	39
Table 3.13: TEST_PH1, The Expansion Header pin out .....	39
Table 3.14: Mini-USB Connector pin out.....	40
Table 3.15: TMDXEVM6670L EVM Board Switches.....	41
Table 3.16: SW3-SW6, DSP Configuration Switch .....	42
Table 3.17: SW9, DSP PCIESEN and User Switch /DSPCLKSEL/PACKSEL.....	43
Table 3.18: TMDXEVM6670L EVM Board Test Points.....	45
Table 3.19: TMDXEVM6670L EVM Board LEDs .....	46
Table 4.1: EVM Voltage Table .....	48
Table 4.2: Each Current Requirements on each device of EVM board .....	49
Table 4.3: The power-up and down timing on the TMDXEVM6670L.....	55
Table 5.1: TMDXEVM6670L EVM FPGA Pin Description.....	59
Table 5.2: The LED states for Power-on Sequence.....	67
Table 5.3: The LED states for Power Failure .....	68
Table 5.4: CLK1, CDCE62002 Register configurations .....	77
Table 5.5: CLK2, CDCE62005 Register configurations .....	77
Table 5.6: CLK3, CDCE62005 Register configurations .....	78
Table 5.7: TMDXEVM6670L EVM FPGA Memory Map.....	78
Table 5.6: FPGA Configuration Registers Summary .....	79

# 1. Overview

---

This chapter provides an overview of the TMDXEVM6670L along with the key features and block diagram.

## 1.1 Key Features

### 1.2 Functional Overview

### 1.3 Basic Operation

### 1.4 Configuration Switch Settings

### 1.5 Power Supply

## 1.1 Key Features

The TMDXEVM6670L is a high-performance, cost-efficient, standalone development platform that enables users to evaluate and develop applications for the Texas Instruments TMS320C6670 Digital Signal Processor (DSP). The Evaluation Module (EVM) also serves as a hardware reference design platform for the TMS320C6670 DSP. The EVM's form-factor is equivalent to a single-wide PICMG® AMC.0 R2.0 *AdvancedMC* module.

Schematics, code examples, and application notes are available to ease the hardware development process and to reduce the time to market.

The key features of the TMDXEVM6670L EVM are:

- Texas Instruments multicore DSP – TMS320C6670
- 512 Mbytes of DDR3-1333 memory
- 64 Mbytes of NAND Flash
- 16MB SPI NOR FLASH
- Two Gigabit Ethernet ports supporting 10/100/1000 Mbps data-rate – one on AMC connector and one RJ-45 connector
- 170-pin B+ style AMC interface
- High Performance connector for the HyperLink interface
- 128K-byte I2C EEPROM for booting
- 2 User LEDs, 5 Banks of DIP Switches and 4 Software-controlled LEDs
- RS232 Serial interface on 3-pin header or UART over mini-USB connector
- Timer, SPI, GPIO and UART signals on the 80-pin expansion header
- Onboard XDS100 type emulation using high-speed USB 2.0 interface

- TI 60-Pin JTAG header to support all external emulator types
- Optional XDS560v2 System Trace Emulation Mezzanine Card
- Module Management Controller (MMC) for Intelligent Platform Management Interface (IPMI)
- Powered by DC power-brick adaptor (12 V/3.0 A) or AMC carrier backplane
- PICMG® AMC.0 R2.0 single width, full height *AdvancedMC* module

## 1.2 Functional Overview

The TMS320C6670 Communications Infrastructure KeyStone SoC is a member of the C66xx SoC family based on TI's new KeyStone Multicore SoC Architecture designed specifically for high-performance wireless infrastructure applications. The TMS320C6670 provides a very high performance macro basestation platform for developing all wireless standards including WCDMA/HSPA/HSPA+, TD-SCDMA, GSM, TDD-LTE, FDD-LTE, and WiMAX. The C6670 also sets a new standard for clock speed with operating frequencies up to 1.2 GHz.

TI's SoC architecture provides a programmable platform integrating various subsystems (C66x cores, IP network, radio layers 1 and 2, and transport processing) and uses a queue-based communication system that allows the SoC resources to operate efficiently and seamlessly. This unique SoC architecture also includes a TeraNet Switch that enables the wide mix of system elements, from programmable cores to dedicated coprocessors and high-speed IO, to operate at maximum efficiency with no blocking or stalling.

The functional block diagram of TMDXEVM6670L is shown in the figure below:




Figure 1.1: Block Diagram of TMDXEVM6670L EVM

## 1.3 Basic Operation

The TMDXEVM6670L platform is designed to work with TI's Code Composer Studio (CCS) development environment and ships with a version specifically tailored for this board. CCS can interface with the board via on-board emulation circuitry using the USB cable supplied

with this EVM or through an external emulator.

The EVM comes with the Texas Instruments Multicore Software Development Kit (MCSDK) for SYS/BIOS OS. The BIOS MCSDK provides the core foundational building blocks that facilitate application software development on TI's high performance and multicore DSPs. The MCSDK also includes an out-of-box demonstration; see the "MCSDK Getting Started Guide".

To start operating the board, follow instructions in the Quick Start Guide. This guide provides instruction for proper connections and configuration for running the POST and OOB Demos. After completing the POST and OOB Demos, proceed with installing CCS and the EVM support files by following the instructions on the DVD. This process will install all the necessary development tools, drivers and documentation.

After the installation has completed, follow the steps below to run Code Composer Studio.

1. Power-on the board using the power brick adaptor (12 V/3.0 A) supplied with this EVM or insert this EVM board into a MicroTCA chassis or AMC carrier backplane.
2. Connect the USB cable from host PC to the EVM board.
3. Launch Code Composer Studio from the host PC by double clicking on its icon on the PC desktop.

Detailed information about the EVM including examples and reference materials are available in the DVD included with this EVM kit.




Figure 1.2: TMDXEVM6670L EVM Layout

## 1.4 Boot Mode and Boot Configuration Switch Setting

The TMDXEVM6670L has 20 sliding DIP switches (Board Ref. SW3 to SW6 and SW9) to determine boot mode, boot configuration, device number, endian mode, CorePac PLL clock selection, and PCIe Mode selection options at the POR stage of the DSP.

## 1.5 Power Supply

The TMDXEVM6670L can be powered from a single +12V / 3.0A DC (36W) external power supply connected to the DC power jack (DC\_IN1). Internally, +12-V input is converted into required voltage levels using local DC-DC converters.

- CVDD (+0.70 V~+1.10 V) is used for the DSP core logic
- +1.0 V is used for internal memory and HyperLink / SRIO / SGMII / PCIe / AIF2 termination of DSP
- +1.5 V is used for DDR3 of DSP, Supplying HyperLink / SRIO / SGMII / PCIe / AIF2 regulators in DSP and RAM chips
- +1.8 V is used for DSP PLLs, DSP LVCMOS I/Os, FPGA I/Os driving the DSP
- +2.5 V is used for the Gigabit Ethernet PHY core
- +1.2 V is used for FPGA core and Gigabit Ethernet PHY core
- +3.3 V is used for the FPGA I/Os
- +5 V and +3.3 V is used to power the XDS560v2 mezzanine card
- The DC power jack connector is a 2.5mm barrel-type plug with positive polarity on the center tip

The TMDXEVM6670L can also draw power from the AMC edge connector (AMC1). If the board is inserted into a PICMG® MicroTCA.0 R1.0-compliant system chassis or AMC Carrier backplane, an external +12 V supply from DC jack (DC\_IN1) is not required.

## 2. Introduction to the TMDXEVM6670L board

---

This chapter provides an introduction and details of interfaces for the TMDXEVM6670L board. It contains:

- 2.1 Memory Map
- 2.2 EVM Boot mode and Boot configuration switch settings
- 2.3 JTAG - Emulation Overview
- 2.4 Clock Domains
- 2.5 None-Volatile Memories (I<sup>2</sup>C EEPROM / SPI NOR Flash / NAND flash)
- 2.6 FPGA Functions
- 2.7 Gigabit Ethernet Connections
- 2.8 Serial RapidIO (SRIO) Interface
- 2.9 DDR3 External Memory Interface
- 2.10 HyperLink Interface
- 2.11 PCI express interface
- 2.12 Antenna Interface (AIF2)
- 2.13 UART Interfaces
- 2.14 Module Management Controller for IPMI
- 2.15 Expansion Headers

### 2.1 Memory Map

The memory map of the TMS320C6670 device is as shown in Table 2.1. The external memory configuration register address ranges in the TMS320C6670 device begin at the hex address location 0x8000 0000 for the DDR3 Memory Controller.

Table 2.1: TMS320C6670 Memory Map

Logical 32 bit Address		Physical 36 bit Address		Bytes	Description
Start	End	Start	End		
0080 0000	008F FFFF	0 0080 0000	0 008F FFFF	1M	L2 SRAM
00E0 0000	00E0 7FFF	0 00E00000	0 00E0 7FFF	32K	L1P SRAM
00F0 0000	00F0 7FFF	0 00F00000	0 00F0 7FFF	32K	L1D SRAM
0100 0000	01BF FFFF	0 0100 0000	0 01BF FFFF	12 M	C66x CorePac Registers
01D0 0000	01D0 007F	0 01D0 0000	0 01D0 007F	128	Tracer 0
01D0 8000	01D0 807F	0 01D0 8000	0 01D0 807F	128	Tracer 1
01D1 0000	01D1 007F	0 01D1 0000	0 01D1 007F	128	Tracer 2
01D1 8000	01D1 807F	0 01D1 8000	0 01D1 807F	128	Tracer 3
01D2 0000	01D2 007F	0 01D2 0000	0 01D2 007F	128	Tracer 4
01D2 8000	01D2 807F	0 01D2 8000	0 01D2 807F	128	Tracer 5
01D3 0000	01D3 007F	0 01D3 0000	0 01D3 007F	128	Tracer 6
01D3 8000	01D3 807F	0 01D3 8000	0 01D3 807F	128	Tracer 7
01D4 0000	01D4 007F	0 01D4 0000	0 01D4 007F	128	Tracer 8
01D4 8000	01D4 807F	0 01D4 8000	0 01D4 807F	128	Tracer 9
01D5 0000	01D5 007F	0 01D5 0000	0 01D5 007F	128	Tracer 10
01D5 8000	01D5 807F	0 01D5 8000	0 01D5 807F	128	Tracer 11
01D6 0000	01D6 007F	0 01D6 0000	0 01D6 007F	128	Tracer 12
01D6 8000	01D6 807F	0 01D6 8000	0 01D6 807F	128	Tracer 13
01D7 0000	01D7 007F	0 01D7 0000	0 01D7 007F	128	Tracer 14
01D7 8000	01D7 807F	0 01D7 8000	0 01D7 807F	128	Tracer 15
01F0 0000	01F7 FFFF	0 01F0 0000	0 01F7 FFFF	512k	AIF2 Control
0200 0000	0208 FFFF	0 0200 0000	0 0208 FFFF	576K	Packet Accelerator Configuration
0209 0000	020B FFFF	0 0209 0000	0 020B FFFF	192K	Ethernet Switch Subsystem Configuration
020C 0000	020F FFFF	0 020C 0000	0 020F FFFF	256K	Security Accelerator Subsystem Configuration
021C 0000	021C 03FF	0 021C 0000	0 021C 03FF	1K	TCP3d-A
021C 8000	021C 83FF	0 021C 8000	0 021C 83FF	1K	TCP3d-B
021D 0000	021D 00FF	0 021D 0000	0 021D 00FF	256	VCP2_A
021D 4000	021D 40FF	0 021D 4000	0 021D 40FF	256	VCP2_B
021D 8000	021D 80FF	0 021D 8000	0 021D 80FF	256	VCP2_C
021D C000	021D C0FF	0 021D C000	0 021D C0FF	256	VCP2_D
021E 0000	021E 0FFF	0 021E 0000	0 021E 0FFF	4K	TCP3e
021F 0000	021F 07FF	0 021F 0000	0 021F 07FF	2K	FFTC-A Configuration
021F 4000	021F 47FF	0 021F 4000	0 021F 47FF	2K	FFTC-B Configuration
0220 0000	0220 007F	0 0220 0000	0 0220 007F	128	Timer0
0221 0000	0221 007F	0 0221 0000	0 0221 007F	128	Timer1
0222 0000	0222 007F	0 0222 0000	0 0222 007F	128	Timer2
0223 0000	0223 007F	0 0223 0000	0 0223 007F	128	Timer3
0224 0000	0224 007F	0 0224 0000	0 0224 007F	128	Timer4
0225 0000	0225 007F	0 0225 0000	0 0225 007F	128	Timer5
0226 0000	0226 007F	0 0226 0000	0 0226 007F	128	Timer6
0227 0000	0227 007F	0 0227 0000	0 0227 007F	128	Timer7
0231 0000	0231 01FF	0 0231 0000	0 0231 01FF	512	PLL Controller
0232 0000	0232 00FF	0 0232 0000	0 0232 00FF	256	GPIO
0233 0000	0233 03FF	0 0233 0000	0 0233 03FF	1K	SmartReflex
0235 0000	0235 0FFF	0 0235 0000	0 0235 0FFF	4K	Power Sleep Controller
0236 0000	0236 03FF	0 0236 0000	0 0236 03FF	1K	Memory Protection Unit (MPU) 0



0236 8000	0236 83FF	0 0236 8000	0 0236 83FF	1K	Memory Protection Unit (MPU) 1
0237 0000	0237 03FF	0 0237 0000	0 0237 03FF	1K	Memory Protection Unit (MPU) 2
0237 8000	0237 83FF	0 0237 8000	0 0237 83FF	1K	Memory Protection Unit (MPU) 3
0244 0000	0244 3FFF	0 0244 0000	0 0244 3FFF	16K	DSP Trace Formatter 0
0245 0000	0245 3FFF	0 0245 0000	0 0245 3FFF	16K	DSP Trace Formatter 1
0246 0000	0246 3FFF	0 0246 0000	0 0246 3FFF	16K	DSP Trace Formatter 2
0247 0000	0247 3FFF	0 0247 0000	0 0247 3FFF	16K	DSP Trace Formatter 3
0253 0000	0253 007F	0 0253 0000	0 0253 007F	128	I2C Data & Control
0254 0000	0254 003F	0 0254 0000	0 0254 003F	64	UART
0260 0000	0260 1FFF	0 0260 0000	0 0260 1FFF	8K	Secondary Interrupt Contoller (INTC) 0
0260 4000	0260 5FFF	0 0260 4000	0 0260 5FFF	8K	Secondary Interrupt Contoller (INTC) 1
0260 8000	0260 9FFF	0 0260 8000	0 0260 9FFF	8K	Secondary Interrupt Contoller (INTC) 2
0262 0000	0262 03FF	0 0262 0000	0 0262 03FF	1K	Chip-Level Registers
0264 0000	0264 07FF	0 0264 0000	0 0264 07FF	2K	Semaphore
0270 0000	0270 7FFF	0 0270 0000	0 0270 7FFF	32K	EDMA Channel Controller (TPCC) 0
0272 0000	0272 7FFF	0 0272 0000	0 0272 7FFF	32K	EDMA Channel Controller (TPCC) 1
02740000	0274 7FFF	0 02740000	0 0274 7FFF	32K	EDMA Channel Controller (TPCC) 2
0276 0000	0276 03FF	0 0276 0000	0 0276 03FF	1K	EDMA TPCC0 Transfer Controller (TPTC) 0
0276 8000	0276 83FF	0 0276 8000	0 0276 83FF	1K	EDMA TPCC0 Transfer Controller (TPTC) 1
0277 0000	0277 03FF	0 0277 0000	0 0277 03FF	1K	EDMA TPCC1 Transfer Controller (TPTC) 0
0277 8000	0277 83FF	0 0277 8000	0 0277 83FF	1K	EDMA TPCC1 Transfer Controller (TPTC) 1
0278 0000	0278 03FF	0 0278 0000	0 0278 03FF	1K	EDMA TPCC1 Transfer Controller (TPTC) 2
0278 8000	0278 83FF	0 0278 8000	0 0278 83FF	1K	EDMA TPCC1 Transfer Controller (TPTC) 3
0279 0000	0279 03FF	0 0279 0000	0 0279 03FF	1K	EDMA TPCC2 Transfer Controller (TPTC) 0
0279 8000	0279 83FF	0 0279 8000	0 0279 83FF	1K	EDMA TPCC2 Transfer Controller (TPTC) 1
027A 0000	027A 03FF	0 027A 0000	0 027A 03FF	1K	EDMA TPCC2 Transfer Controller (TPTC) 2
027A 8000	027A 83FF	0 027A 8000	0 027A 83FF	1K	EDMA TPCC2 Transfer Controller (TPTC) 3
027D 0000	027D 3FFF	0 027D 0000	0 027D 3FFF	16k	TI Embedded Trace Buffer (TETB) - Core 0
027E 0000	027E 3FFF	0 027E 0000	0 027E 3FFF	16k	TI Embedded Trace Buffer (TETB) - Core 1
027F 0000	027F 3FFF	0 027F 0000	0 027F 3FFF	16k	TI Embedded Trace Buffer (TETB) - Core 2
0280 0000	0280 3FFF	0 0280 0000	0 0280 3FFF	16k	TI Embedded Trace Buffer (TETB) - Core 3
0285 0000	0285 7FFF	0 0285 0000	0 0285 7FFF	32k	TI Embedded Trace Buffer

					(TETB) - System
0290 0000	0290 7FFF	0 0290 0000	0 0290 7FFF	32K	Serial RapidIO Configuration
02A0 0000	02AF FFFF	0 02A0 0000	0 02AF FFFF	1M	Queue Manager Subsystem Configuration
0800 0000	0800 FFFF	0 0800 0000	0 0800 FFFF	64k	Extended Memory Controller (XMC) Configuration
0BC0 0000	0BCF FFFF	0 0BC0 0000	0 0BCF FFFF	1M	Multicore Shared Memory Controller (MSMC) Config
0C00 0000	0C1F FFFF	0 0C00 0000	0 0C1F FFFF	2M	Multicore Shared Memory (MSM)
1080 0000	108F FFFF	0 1080 0000	0 108F FFFF	1M	Core 0 L2 SRAM
10E0 0000	10E0 7FFF	0 10E0 0000	0 10E0 7FFF	32k	Core 0 L1P SRAM
10F0 0000	10F0 7FFF	0 10F0 0000	0 10F0 7FFF	32k	Core 0 L1D SRAM
1180 0000	118F FFFF	0 1180 0000	0 118F FFFF	1M	Core 1 L2 SRAM
11E0 0000	11E0 7FFF	0 11E0 0000	0 11E0 7FFF	32k	Core 1 L1P SRAM
11F0 0000	11F0 7FFF	0 11F0 0000	0 11F0 7FFF	32k	Core 1 L1D SRAM
1280 0000	128F FFFF	0 1280 0000	0 128F FFFF	1M	Core 2 L2 SRAM
12E0 0000	12E0 7FFF	0 12E0 0000	0 12E0 7FFF	32k	Core 2 L1P SRAM
12F0 0000	12F0 7FFF	0 12F0 0000	0 12F0 7FFF	32k	Core 2 L1D SRAM
1380 0000	1388 FFFF	0 1380 0000	0 1388 FFFF	1M	Core 3 L2 SRAM
13E0 0000	13E0 7FFF	0 13E0 0000	0 13E0 7FFF	32k	Core 3 L1P SRAM
13F0 0000	13F0 7FFF	0 13F0 0000	0 13F0 7FFF	32k	Core 3 L1D SRAM
2000 0000	200F FFFF	0 2000 0000	0 200F FFFF	1M	System Trace Manager (STM) Configuration
2060 0000	206F FFFF	0 2060 0000	0 206F FFFF	1M	TCP3d-B Data
2080 0000	208F FFFF	0 2080 0000	0 208F FFFF	1M	TCP3d-A Data
2090 0000	2090 1FFF	0 2090 0000	0 2090 1FFF	8K	TCP3e Data Write Port
2090 2000	2090 3FFF	0 2090 2000	0 2090 3FFF	8K	TCP3e Data Read Port
20B0 0000	20B1 FFFF	0 20B0 0000	0 20B1 FFFF	128k	Boot ROM
20BF 0000	20BF 03FF	0 20BF 0000	0 20BF 03FF	1k	SPI
2100 0000	2100 00FF	0 2100 0000	0 2100 00FF	256	DDR3 EMIF Configuration
2140 0000	2140 03FF	0 2140 0000	0 2140 03FF	1K	HyperLink Config
2180 0000	2180 7FFF	0 2180 0000	0 2180 7FFF	32K	PCIe Config
22A0 0000	22A0 FFFF	0 22A0 0000	0 22A0 FFFF	64K	VCP2_A
22B0 0000	22B0 FFFF	0 22B0 0000	0 22B0 FFFF	64K	VCP2_B
22C0 0000	22C0 FFFF	0 22C0 0000	0 22C0 FFFF	64K	VCP2_C
22D0 0000	22D0 FFFF	0 22D0 0000	0 22D0 FFFF	64K	VCP2_D
3400 0000	341F FFFF	0 3400 0000	0 341F FFFF	2M	Queue Manager Subsystem Data
4000 0000	4FFF FFFF	0 4000 0000	0 4FFF FFFF	256M	HyperLink Data
6000 0000	6FFF FFFF	0 6000 0000	0 6FFF FFFF	256M	PCIe Data
8000 0000	FFFF FFFF	8 8000 0000	8 FFFF FFFF	2G	DDR3 EMIF Data

## 2.2 EVM Boot Mode and Boot Configuration Switch Settings

The TMDXEVM6670L has five configuration switches: SW3, SW4, SW5, SW6 and SW9 that contain 19 individual values latched when reset is released. This occurs when power is applied on the board, after the user presses the FULL\_RESET push button or after a POR reset is requested from the MMC.

SW3 determines the general DSP configuration, Little or Big Endian mode, and boot device selection.

SW4, SW5, SW6 and SW9 determine the DSP boot device configuration, CorePac PLL setting and PCIe mode selection.

More information about using these DIP switches is contained in Section 3.3 of this document. For more information on DSP supported Boot Modes, refer to [TMS320C6670 Data Manual](#) and [C66x Bootloader User Guide](#).

## 2.3 JTAG - Emulation Overview

The TMDXEVM6670L has onboard embedded JTAG emulation circuitry; users do not require an external emulator to connect the EVM with Code Composer Studio. Users can connect CCS with the target DSP in the EVM through the USB cable supplied along with this board.

In case users wish to connect an external emulator to the EVM, the TI 60-pin JTAG header (EMU1) is provided for high speed real-time emulation. The TI 60-pin JTAG supports all standard TI DSP emulators. An adapter will be required for use with some emulators.

The on-board embedded JTAG emulator is the default connection to the DSP. However when an external emulator is connected to EVM, the board circuitry switches automatically to give emulation control to the external emulator.

When the on-board emulator and external emulator are connected at the same time, the external emulator has priority and the onboard emulator is disconnected from the DSP.

The third way of accessing the DSP is through the JTAG port on the AMC edge connector, users can connect the DSP through the AMC backplane if they don't use the XDS100 on-board emulator and the 60-pin header with the external emulator.

The JTAG interface among the DSP, on-board emulator, external emulator and the AMC edge connector is shown in the below figure:




Figure 2.1: TMDXEVM6670L EVM JTAG emulation

## 2.4 Clock Domains

The EVM incorporates a variety of clocks to the TMS320C6670 DSP as well as other devices that are configured automatically during the power up configuration sequence. The figure below illustrates clocking for the system in the EVM module.

A new feature on the Rev 3.0 EVM boards is support for external clock references. This is needed for some applications using the AIF and HyperLink SERDES interfaces. The external reference clock is driven into the clock generation device rather than using the local crystal. For AIF, a common 30.72MHz timing source is needed for the clock generator, CLK3, that drives the CORE\_CLK and SYS\_CLK inputs. It is supplied on the AMC connector at the TCLKD input. For HyperLink, a common 25MHz timing source is needed for the clock generator, CLK2, that drives the MCM\_CLK input. It is supplied on the AMC connector at the TCLKB input.




Figure 2.2: TMDXEVM6670L EVM Clock Domains

## 2.5 Non-Volatile Memories (SEEPROM / SPI NOR Flash / NAND flash)

The I2C modules on the TMS320C6670 may be used by the DSP to control local peripheral ICs (DACs, ADCs, etc.) or may be used to communicate with other controllers in a system or to implement a user interface.

The I2C bus is connected to one SEEPROM and to the 80-pin expansion header (TEST\_PH1). There are two banks in the I2C SEEPROM which respond separately at addresses 0x50 and 0x51. These banks can be loaded with demonstration programs. Currently, the bank at 0x50 contains the I2C boot code and PLL initialization procedure and the bank at 0x51 contains the second level boot-loader program. The second level boot-loader can be used to run the POST program or launch the OOB demonstration from NOR flash memory.

The serial peripheral interconnect (SPI) module provides an interface between the DSP and other SPI-compliant devices. The primary intent of this interface is to allow for connection to a SPI ROM for boot. The SPI module on TMS320C6670 is supported only in Master mode.

The NOR FLASH attached to CS0z on the TMS320C6670 is a NUMONYX N25Q128A21. This NOR FLASH size is 16MB. It can contain demonstration programs such as POST or the OOB demonstration. The CS1z of the SPI is used by the DSP to access registers within the FPGA.

The NAND flash is connected by the TMS320C6670 GPIO pins to access the 64M bytes NAND flash, the GPIO pins on the TMS320C6670 connected to the FPGA are only used to boot configurations during the Power-on period on the EVM. The function block and pin connections are shown in the following figure and table.




Figure 2.3: TMDXEVM6670L EVM NAND flash connections

DSP GPIO	NAND Flash	Pin Description
GPIO[7:0]	I/O[7:0]	The 8-bit data bus
GPIO8	CL	The Command Latch Enable pin
GPIO9	AL	The Address Latch Enable pin
GPIO10	WE#	The Write Enable pin
GPIO11	R/B#	The Ready/Busy# pin
GPIO12	RE#	The Read Enable pin
GPIO13	CE#	The Chip Enable pin
NAND_WP# Driving by FPGA	WP#	The Write Protect pin (It's controlled by the FPGA)

Table 2.2: TMDXEVM6670L EVM NAND flash connections

## 2.6 FPGA Functions

The FPGA (Xilinx XC3S200AN) controls the reset mechanism of the DSP and provides boot mode and boot configuration data to the DSP through SW3, SW4, SW5, SW6 and SW9. The FPGA also provides the transformation of TCLK[A:D] from AMC connector for the Timer of the DSP, user LEDs control, and one user switch through control registers. All FPGA registers are accessible over the SPI interface.

The figure below shows the interface between TMS320C6670 DSP and FPGA.




Figure 2.4: TMDXEVM6670L EVM FPGA Connections

## 2.7 Gigabit Ethernet Connections

The TMDXEVM6670L provides connectivity for both SGMII Gigabit Ethernet ports on the EVM. These are shown in figure below:




Figure 2.5: TMDXEVM6670L EVM Ethernet Routing

The Ethernet PHY (PHY1) is connected to DSP EMAC1 to provide a copper interface and routed to a Gigabit RJ-45 connector (LAN1). The EMAC0 of DSP is routed to Port0 of the AMC edge connector backplane interface.

## 2.8 Serial RapidIO (SRIO) Interface

The TMDXEVM6670L supports high speed SERDES based Serial RapidIO (SRIO) interface. There are total 4 RapidIO ports available on TMS320C6670. All SRIO ports are routed to AMC edge connector on board. Below figure shows RapidIO connections between the DSP and AMC edge connector.




Figure 2.6: TMDXEVM6670L EVM SRIO Port Connections

## 2.9 DDR3 External Memory Interface

The TMS320C6670 DDR3 interface connects to four 1Gbit (64Meg x 16) DDR3 1333 devices. This configuration allows the use of both “narrow (16-bit)”, “normal (32-bit)”, and “wide (64-bit)” modes of the DDR3 EMIF.

SAMSUNG DDR3 SDRAMs (64Mx16-bit; 1333MT/s) are used on the DDR3 EMIF.

Below figure illustrates the implementation for the DDR3 SDRAM memory.






Figure 2.7: TMDXEVM6670L EVM SDRAM

## 2.10 HyperLink interface

The TMS320C6670 provides the HyperLink bus for companion chip/die interfaces. This is a four-lane SerDes interface designed to operate at 12.5 Gbps per lane. The interface is used to connect with external accelerators.

The interface includes the Serial Station Management Interfaces used to send power management and flow messages between devices. This consists of four LVCMOS inputs and four LVCMOS outputs configured as two 2-wire output buses and two 2-wire input buses. Each 2-wire bus includes a data signal and a clock signal.

Below figure illustrates the HyperLink bus connections on the TMDXEVM6670L EVM.




Figure 2.8: TMDXEVM6670L EVM HyperLink connections

## 2.11 PCI express interface

The 2 lane PCI express (PCIe) interface on TMDXEVM6670L provides a connection between the DSP and AMC edge connector. The PCI Express interface provides low pin count, high reliability, and high-speed data transfer at rates of 5.0 Gbps per lane on the serial links. For more information, see the Peripheral Component Interconnect Express (PCIe) for KeyStone Devices User Guide (literature number SPRUGS6).

The TMDXEVM6670L provides the PCIe connectivity to AMC backplane on the EVM, this is shown in below figure.




Figure 2.9: TMDXEVM6670L EVM PCIE Port Connections

## 2.12 Antenna Interface (AIF2)

The TMS320C6670 supports a high-speed SERDES-based Antenna Interface (AIF2) that operates up to 6.144Gbps. A six-lane SerDes-based Antenna Interface is available on the TMDXEVM6670. All Antenna Interface ports are routed to the AMC edge connector on the board.

Below figure shows the AIF connections on the TMDXEVM6670L EVM.




Figure 2.10: TMDXEVM6670L EVM AIF Port Connections

## 2.13 UART Interface

A serial port is provided for UART communication by the TMS320C6670. This serial port can be accessed either through the USB connector (USB1) or through the three-pin (Tx, Rx, and GND) serial port header (COM1). The selection can be made through the UART Route Select shunt-post COM\_SEL1 as follows:

- UART over mini-USB Connector - Shunts installed over COM\_SEL1.3- COM\_SEL1.1 and COM\_SEL1.4 - COM\_SEL1.2 (**Default**)
- UART over 3-Pin Header (COM1) - Shunts installed over COM\_SEL1.3- COM\_SEL1.5 and COM\_SEL1.4 –COM\_SEL1.6




Figure 2.11: TMDXEVM6670L EVM UART Connections

## 2.14 Module Management Controller (MMC) for IPMI

The TMDXEVM6670L supports a limited set of Intelligent Platform Management Interface (IPMI) commands using the Module Management Controller (MMC) based on Texas Instruments MSP430F5435 mixed-signal processor.

The MMC communicates with the MicroTCA Carrier Hub (MCH) over the IPMB (Intelligent Platform Management Bus) when inserted into an AMC slot of a PICMG® MTCA.0 R1.0-compliant chassis. The primary purpose of the MMC is to provide necessary information to the MCH, to enable the payload power to the TMDXEVM6670L EVM when it is inserted into the MicroTCA chassis.

The EVM also supports a Blue LED (D2) and Red LED (D1) on the front panel as specified in PICMG® AMC.0 R2.0 AdvancedMC base specification. Both of these LEDs will blink as part of the initialization process when the MMC receives management power.

Blue LED (D2):

The blue LED comes ON when MicroTCA chassis is powered ON and an EVM is inserted into it. The blue LED goes OFF when payload power is enabled to the EVM by the MCH.

Red LED (D1):

Red colored (D1) will normally be OFF. It will turn ON to provide basic feedback about failures and out of service.




Figure 2.12: TMDXEVM6670L EVM MMC Connections for IPMI

## 2.15 Expansion Headers

The TMDXEVM6670L contains an 80-pin header (TEST\_PH1) which has I<sup>2</sup>C, TIMI[0:1], TIMO[0:1], SPI, GPIO[15:0], and UART signal connections. It should be noted that I<sup>2</sup>C, TIMI[1:0], TIMO[0:1], and SPI GPIO[15:0] connections to this header (TEST\_PH1) are 1.8 V whereas UART signals are 3.3 V level.

### 3. TMDXEVM6670L Board Physical Specifications

---

This chapter describes the physical layout of the TMDXEVM6670L board and its connectors, switches, and test points. It contains:

#### 3.1 Board Layout

#### 3.2 Connector Index

#### 3.3 Switches

#### 3.4 Test Points

#### 3.5 System LEDs

### 3.1 Board Layout

The TMDXEVM6670L board dimension is 7.11" x 2.89" (180.6mm x 73.5mm). It is a 12-layer board and powered through connector DC\_IN1. Figure 3.1 and 3.2 show assembly layout of the TMDXEVM6670L EVM Board.




Figure 3.1: TMDXEVM6670L EVM Board Assembly Layout – TOP view




Figure 3.2: TMDXEVM6670L EVM Board layout – Bottom view

### 3.2 Connector Index

The TMDXEVM6670L Board has several connectors that provide access to various interfaces on the board.

Table 3.1: TMDXEVM6670L EVM Board Connectors

Connector	Pins	Function
560V2_PWR1	8	XDS560v2 Mezzanine Power Connector
AMC1	170	AMC Edge Connector
COM1	3	UART 3-Pin Connector
COM_SEL1	6	UART Route Select Jumper
DC_IN1	3	DC Power Input Jack Connector
EMU1	60	TI 60-Pin DSP JTAG Connector
FAN1	3	FAN connector for +12V DC FAN
HyperLink1	36	HyperLink connector for companion chip/die interface
LAN1	12	Gigabit Ethernet RJ-45 Connector
PMBUS1	5	PMBUS for Smart-Reflex connected to UCD9222
TAP_FPGA1	8	FPGA JTAG Connector
SBW_MMC1	4	MSP430 Spy-Bi-Wire Connector -- For Factory Use Only
TEST_PH1	80	SPI, I <sup>2</sup> C, GPIO, TIMI[1:0], TIMO[1:0], and UART1 connections
USB1	5	Mini-USB Connector

### 3.2.1 560V2\_PWR1, XDS560v2 Mezzanine Power Connector

560V2\_PWR1 is an 8-pin power connector for the XDS560v2 mezzanine emulator board. The pin out of the connector is shown in the table below:

Table 3.2: XDS560v2 Power Connector pin out

Pin #	Signal Name
1	+5VSupply
2	+5VSupply
3	XDS560V2_IL
4	Ground
5	+3.3VSupply
6	+3.3VSupply
7	Ground
8	Ground

### 3.2.2 AMC1, AMC Edge Connector

The AMC card-edge connector plugs into an AMC compatible carrier board and provides 4 Serial RapidIO lanes, 2 PCIe lanes, 1 SGMII port, 6 AIF2 lanes and the system interfaces to the carrier board. This connector is the 170 pin B+ style. The signals on this connector are shown in the table below.

Please note that the TCLKB and TCLKD on the Rev 3.0 EVM can now be used as optional common clock sources to synchronize the timing between two EVMs for the HyperLink and AIF interfaces. Also, the TCLKC pins can now be used as C6670 timer input and output signals buffered through the FPGA..

Table 3.3: AMC Edge Connector

Pin	Signal	Pin	Signal
1	GND	170	GND
2	VCC12	169	AMC_JTAG_TDI
3	MMC_PS_N1#	168	AMC_JTAG_TDO
4	VCC3V3_MP_AMC	167	AMC_JTAG_RST#
5	MMC_GA0	166	AMC_JTAG_TMS
6	RSVD	165	AMC_JTAG_TCK
7	GND	164	GND
8	RSVD	163	AMC_RP1CLKP
9	VCC12	162	AMC_RP1CLKN
10	GND	161	GND
11	AMC0_SGMII0_TX_DP	160	AMC_EXP_SCL
12	AMC0_SGMII0_TX_DP	159	AMC_EXP_SDA
13	GND	158	GND
14	AMC0_SGMII0_RX_DP	157	RP1FBP

Pin	Signal	Pin	Signal
15	AMC0_SGMII0_RX_DN	156	RP1FBN
16	GND	155	GND
17	MMC_GA1	154	PHYSYNC
18	VCC12	153	RADSYNC
19	GND	152	GND
20	NC	151	AMCC_P18_AIF5_TXP
21	NC	150	AMCC_P18_AIF5_TXN
22	GND	149	GND
23	NC	148	AMCC_P18_AIF5_RXP
24	NC	147	AMCC_P18_AIF5_RXN
25	GND	146	GND
26	MMC_GA2	145	AMCC_P17_AIF4_TXP
27	VCC12	144	AMCC_P17_AIF4_TXN
28	GND	143	GND
29	NC	142	AMCC_P17_AIF4_RXP
30	NC	141	AMCC_P17_AIF4_RXN
31	GND	140	GND
32	NC	139	TCLKD_P / CLK3_PRI_P
33	NC	138	TCLKD_N / CLK3_PRI_N
34	GND	137	GND
35	NC	136	TCLKC_P / DSP_TIM00_AMC
36	NC	135	TCLKC_N / DSP_TIMIO_AMC
37	GND	134	GND
38	NC	133	AMCC_P15_AIF3_TXP
39	NC	132	AMCC_P15_AIF3_TXN
40	GND	131	GND
41	MMC_ENABLE_N	130	AMCC_P15_AIF3_RXP
42	VCC12	129	AMCC_P15_AIF3_RXN
43	GND	128	GND
44	AMCC_P4_PCl_e_TX1P	127	AMCC_P14_AIF2_TXP
45	AMCC_P4_PCl_e_TX1N	126	AMCC_P14_AIF2_TXN
46	GND	125	GND
47	AMCC_P4_PCl_e_RX1P	124	AMCC_P14_AIF2_RXP
48	AMCC_P4_PCl_e_RX1N	123	AMCC_P14_AIF2_RXN
49	GND	122	GND
50	AMCC_P5_PCl_e_TX2P	121	AMCC_P13_AIF1_TXP
51	AMCC_P5_PCl_e_TX2N	120	AMCC_P13_AIF1_TXN
52	GND	119	GND
53	AMCC_P5_PCl_e_RX2P	118	AMCC_P13_AIF1_RXP
54	AMCC_P5_PCl_e_RX2N	117	AMCC_P13_AIF1_RXN
55	GND	116	GND
56	SMB_SCL_IPMBL	115	AMCC_P12_AIF0_TXP
57	VCC12	114	AMCC_P12_AIF0_TXN
58	GND	113	GND
59	NC	112	AMCC_P12_AIF0_RXP



Pin	Signal	Pin	Signal
60	NC	111	AMCC_P12_AIF0_RXN
61	GND	110	GND
62	NC	109	AMCC_P11_SRIO4_TXP
63	NC	108	AMCC_P11_SRIO4_TXN
64	GND	107	GND
65	NC	106	AMCC_P11_SRIO4_RXP
66	NC	105	AMCC_P11_SRIO4_RXN
67	GND	104	GND
68	NC	103	AMCC_P10_SRIO3_TXP
69	NC	102	AMCC_P10_SRIO3_TXN
70	GND	101	GND
71	SMB_SDA_IPMBL	100	AMCC_P10_SRIO3_RXP
72	VCC12	99	AMCC_P10_SRIO3_RXN
73	GND	98	GND
74	TCLKA_P	97	AMCC_P9_SRIO2_TXP
75	TCLKA_N	96	AMCC_P9_SRIO2_TXN
76	GND	95	GND
77	TCLKB_P / CLK2_PRI_P	94	AMCC_P9_SRIO2_RXP
78	TCLKB_N / CLK2_PRI_N	93	AMCC_P9_SRIO2_RXN
79	GND	92	GND
80	PCIE_REF_CLK_P	91	AMCC_P8_SRIO1_TXP
81	PCIE_REF_CLK_N	90	AMCC_P8_SRIO1_TXN
82	GND	89	GND
83	MMC_PS_N0	88	AMCC_P8_SRIO1_RXP
84	VCC12	87	AMCC_P8_SRIO1_RXN
85	GND	86	GND

### 3.2.3 COM1, UART 3-Pin Connector

COM1 is a 3-pin male connector for RS232 serial interface. A 3-pin female to 9-pin DTE female cable is supplied with the TMDXEVM6670L to connect with the PC.

Table 3.4: UART Connector pin out

Pin #	Signal Name
1	Receive
2	Transmit
3	Ground

### 3.2.4 COM\_SEL1, UART Route Select Connector

The UART port can be accessed through the mini-USB connector (USB1) or the three-pin RS232 Serial port header (COM1). The selection can be made through the UART route select connector COM\_SEL1 as follows:


- UART over USB Connector(**Default**): Shunts installed over COM\_SEL1.3-COM\_SEL1.1 and COM\_SEL1.4-COM\_SEL1.2
- UART over three-pin Header LAN1-Shunts installed over COM\_SEL1.3-COM\_SEL1.5 and COM\_SEL1.4-COM\_SEL1.6

The pin out for the connector is shown in the table below:

Table 3.5: UART Path Select Connector pin out

Pin #	Signal Name	Pin #	Signal Name
1	FT2232H (USB Chip) Transmit	2	FT2232H (USB Chip) Receive
3	UART Transmit	4	UART Receive
5	MAX3221 Transmit	6	MAX3221 Receive

Figure 3.3: COM\_SEL1 Jumper setting



### 3.2.5 DC\_IN1, DC Power Input Jack Connector

DC\_IN1 is a DC Power-in jack Connector for the stand-alone application of TMDXEVM6670L. It is a 2.5 mm power jack with positive center tip polarity. Do not use this connector if EVM is inserted into the MicroTCA chassis or the AMC carrier backplane.

### 3.2.6 EMU1, TI 60-Pin DSP JTAG Connector

EMU1 is a high speed system trace capable TI 60-pin JTAG connector for XDS560v2 type of DSP emulation. The on board switch multiplexes this interface with the on board XDS100 type emulator. Whenever an external emulator is plugged into EMU1, the external emulator connection will be switched to the DSP. The I/O voltage level on these pins is 1.8 V. So any 1.8V compatible emulator can be used to interface with the TMS320C6670 DSP. It should be noted that when an external emulator is plugged into this connector (EMU1), on board XDS100 type emulation circuitry will be disconnected from the DSP. The pin out for the connector is shown in the table below:

Table 3.6: TI 60-pin DSP JTAG Connector pin out

Pin #	Signal Name	Pin #	Signal Name
A1	EMU_DET	C1	ID2 (GND)
A2	Ground	C2	EMU18
A3	Ground	C3	TRST#
A4	Ground	C4	EMU16
A5	Ground	C5	EMU15
A6	Ground	C6	EMU13
A7	Ground	C7	EMU11
A8	Type0 (NC)	C8	TCLKRTN
A9	Ground	C9	EMU10
A10	Ground	C10	EMU8
A11	Ground	C11	EMU6
A12	Ground	C12	EMU4
A13	Ground	C13	EMU3
A14	Ground	C14	EMU1
A15	TRGRST#	C15	ID3 (GND)
B1	ID0 (GND)	D1	NC
B2	TMS	D2	Ground
B3	EMU17	D3	Ground
B4	TDI	D4	Ground
B5	EMU14	D5	Ground
B6	EMU12	D6	Ground
B7	TDO	D7	Ground
B8	TVD (+1.8V)	D8	Type1 (GND)
B9	EMU9	D9	Ground
B10	EMU7	D10	Ground
B11	EMU5	D11	Ground
B12	TCLK	D12	Ground
B13	EMU2	D13	Ground
B14	EMU0	D14	Ground
B15	ID1 (GND)	D15	Ground

### 3.2.7 FAN1, FAN Connector

The EVM incorporates a dedicated cooling fan. This fan has the capability of easily being removed when the EVM is inserted into an AMC backplane which uses forced air cooling. The fan selected provides maximum cooling (CFM) and operates on 12Vdc. FAN1 will be connected to provide 12Vdc to the fan.

Table 3.7: FAN1 Connector pin out

Pin #	Signal Name
1	GND
2	+12Vdc
3	NC

### 3.2.8 HyperLink1, HyperLink Connector

The EVM provides a HyperLink connection by a mini-SAS HD+ 4i connector. The connector contains 8 SERDES pairs and 4 sideband sets to carry full HyperLink signals. The connector is shown in Figure 3.4. and its pin out is shown in Table 3.8.




Figure 3.4: The HyperLink Connector

Table 3.8: The HyperLink Connector

Pin#	Net	Pin#	Net
A1	HyperLink_TXFLCLK	B1	HyperLink_RXPMDAT
A2	HyperLink_RXFLCLK	B2	HyperLink_TXFLDAT
A3	GND	B3	GND
A4	HyperLink_RXP1	B4	HyperLink_RXP0
A5	HyperLink_RXN1	B5	HyperLink_RXN0
A6	GND	B6	GND
A7	HyperLink_RXP3	B7	HyperLink_RXP2
A8	HyperLink_RXN3	B8	HyperLink_RXN2
A9	GND	B9	GND
C1	HyperLink_TXPMDAT	D1	HyperLink_RXPMCLK
C2	HyperLink_TXPMCLK	D2	HyperLink_RXFLDAT
C3	GND	D3	GND
C4	HyperLink_TXP1	D4	HyperLink_TXP0
C5	HyperLink_TXN1	D5	HyperLink_TXN0
C6	GND	D6	GND
C7	HyperLink_TXP3	D7	HyperLink_TXP2
C8	HyperLink_TXN3	D8	HyperLink_TXN2
C9	GND	D9	GND

### 3.2.9 LAN1, Ethernet Connector

LAN1 is a Gigabit RJ45 Ethernet connector with integrated magnetics. It is driven by Marvell Gigabit Ethernet transceiver 88E1111. The connections are shown in the table below:

Table 3.9: Ethernet Connector pin out

Pin #	Signal Name
1	Center Tap2
2	MD2-
3	MD2+
4	MD1-
5	MD1+
6	Center Tap1
7	Center Tap3
8	MD3+
9	MD3-
10	MD0-
11	MD0+
12	Center Tap0
13	ACT_LED1-
14	ACT_LED1+
15	LINK1000_LED2-
16	LINK_LED2+
17	LINK100_LED2-
H3	Shield 1
H4	Shield 2

### 3.2.10 PMBUS1, PMBUS Connector for Smart-Reflex Control

The TMS320C6670 DSP core power is supplied by a Smart-Reflex power controller UCD9222 with the Integrated FET Driver UCD74110 and UCD74106. PMBUS1 provides a connection between UCD9222 and remote connection during development. Through the USB to GPIO pod provided by TI, the user can trace and configure the parameters in UCD9222 with the Smart-Fusion GUI. The pin out of PMBUS1 is shown in table 3.10.

Table 3.10: PMBUS1 Pin out

Pin #	Signal Name
1	PMBUS_CLK
2	PMBUS_DAT
3	PMBUS_ALT
4	PMBUS_CTL
5	GND

### 3.2.11 TAP\_FPGA1, FPGA JTAG Connector (For Factory Use Only)

TAP\_FPGA1 is an 8-pin JTAG connector for the FPGA programming and the PHY boundary test of the factory only. The pin out for the connector is shown in the figure below:

Table 3.11: FPGA JTAG Connector pin out

Pin #	Signal Name
1	VCC3V3_FPGA
2	GND
3	BSC_JTAG_TCK
4	BSC_JTAG_TDI
5	BSC_JTAG_TDO
6	BSC_JTAG_TMS
7	BSC_JTAG_RST#
8	BSC_JTAG_P8(PU)

In FPGA debugging and programming mode, pin 8 of BSC\_JTAG\_P8 keep as PU pin to the EVM board.

The diagram of the boundary scan route is shown in Figure 3.4.




Figure 3.5: TAP\_FPGA1 function diagram

### 3.2.12 SBW\_MMC1, MSP430 SpyBiWire Connector (For Factory Use Only)

SBW\_MMC1 is a 4-pin SpyBiWire connector for IPMI software loading into MSP430. The TMDXEVM6670L is supplied with IPMI software already loaded into MSP430. The pin out of the connector is shown in the table below:

Table 3.12: MSP430 SpyBiWire Connector pin out

Pin #	Signal Name
1	GND
2	VCC3V3_MP
3	MMC_SBWTDIO
4	MMC_SBWTCK

### 3.2.13 TEST\_PH1, Expansion Header (SPI, GPIO, Timer I/O, I<sup>2</sup>C, and UART)

TEST\_PH1 is an expansion header for several interfaces on the DSP; there are SPI, GPIO, Timer, I<sup>2</sup>C, and UART. The signal connections to the expansion header are shown in below table:

Table 3.13: TEST\_PH1, The Expansion Header pin out

Pin	Signal	Description	Pin	Signal	Description
1	GND	Ground	2	VCC5	+5V power rail
3	DSP_SDA	DSP I2C data	4	VCC5	+5V power rail
5	DSP_SCL	DSP I2C clock	6	GND	Ground
7	NC		8	GND	Ground
9	NC		10	NC	
11	NC		12	VCC3V3_AUX	+3.3V power rail
13	NC		14	VCC3V3_AUX	+3.3V power rail
15	NC		16	GND	Ground
17	NC		18	GND	Ground
19	NC		20	NC	
21	NC		22	VCC1V8_AUX	+1.8V power rail
23	NC		24	VCC1V8_AUX	+1.8V power rail
25	NC		26	GND	Ground
27	NC		28	GND	Ground
29	NC		30	NC	
31	NC		32	NC	
33	NC		34	NC	
35	NC		36	NC	
37	NC		38	NC	
39	NC		40	NC	
41	NC		42	NC	

43	NC		44	NC	
45	NC		46	NC	
47	CLK2_SYNC	The HyperLink common control signal	48	NC	
49	CLK3_SYNC	The AIF2 common timing control signal	50	DSP_GPIO_00	DSP GPIO0
51	PHYSYNC_R	Radio Sync for AIF2	52	DSP_GPIO_01	DSP GPIO1
53	RADSYNC_R	PHY Sync for AIF2	54	DSP_GPIO_02	DSP GPIO2
55	DSP_TIMIO_80PIN	Timer input 0 to FPGA for the DSP Timer0 input	56	DSP_GPIO_03	DSP GPIO3
57	DSP_TIMO0	Timer output 0	58	DSP_GPIO_04	DSP GPIO4
59	DSP_TIMI1	Timer input 1	60	DSP_GPIO_05	DSP GPIO5
61	DSP_TIMO1	Timer output 1	62	DSP_GPIO_06	DSP GPIO6
63	DSP_SSPMISO	SPI data input	64	DSP_GPIO_07	DSP GPIO7
65	DSP_SSPMOSI	SPI data output	66	DSP_GPIO_08	DSP GPIO8
67	DSP_SSPCS1	SPI chip select	68	DSP_GPIO_09	DSP GPIO9
69	PH_SSPCK	SPI clock	70	DSP_GPIO_10	DSP GPIO10
71	DSP_UARTTXD	UART Serial Data Out(+3.3v)	72	DSP_GPIO_11	DSP GPIO11
73	DSP_UARTRXD	UART Serial Data In (+3.3v)	74	DSP_GPIO_12	DSP GPIO12
75	DSP_UARTRTS	UART Request To Send (+3.3v)	76	DSP_GPIO_13	DSP GPIO13
77	DSP_UARTCTS	UART Cear To Send (+3.3v)	78	DSP_GPIO_14	DSP GPIO14
79	GND	Ground	80	DSP_GPIO_15	DSP GPIO15

### 3.2.14 USB1, Mini-USB Connector

USB1 is a five-pin mini-USB connector to connect Code Composer Studio with the TMS320C6670 DSP using XDS100 type on-board emulation circuitry. The following table shows the Pin out of the mini-USB connector.

Table 3.14: Mini-USB Connector pin out

Pin #	Signal Name
1	VBUS
2	USB D-
3	USB D+
4	ID (NC)
5	Ground



### 3.3 DIP and Pushbutton Switches

The TMDXEVM6670L has 3 push button switches and 5 sliding actuator DIP switches. The RST\_FULL1, RST\_COLD1, and RST\_WARM1 are push button switches while SW3, SW4, SW5, SW6 and SW9 are DIP switches. The function of each of the switches is listed in the table below:

Table 3.15: TMDXEVM6670L EVM Board Switches

Switch	Function
RST_FULL1	Full Reset Event
RST_COLD1	Cold Reset Event (RFU)
RST_WARM1	Warm Reset Event
SW3	DSP Boot mode, DSP Configuration
SW4	DSP boot Configuration
SW5	DSP boot Configuration
SW6	DSP boot Configuration, PLL setting, PCIe mode Selection
SW9	PCIESS Enable/Disable, User Switch DSPCLKSEL and PASSCLKSEL

#### 3.3.1 RST\_FULL1, Full Reset

Pressing the RST\_FULL1 button switch will issue a RESETFULL# to TMS320C6670 by the FPGA. It'll reset DSP and other peripherals.

#### 3.3.2 RST\_COLD1, Cold Reset

The button is reserved for future use.

#### 3.3.3 RST\_WARM1, Warm Reset

Pressing the RST\_WARM1 button switch will issue a RESET# to TMS320C6670 by the FPGA. The FPGA will assert the RESET# signal to the DSP and the DSP will execute either a HARD or SOFT resets by the configuration in the RSCFG register in PLLCTL.

Note: Users may refer to the [TMS320C6670 Data Manual](#) to check the difference between assertion of DSP RESET# and DSP POR# signals.

#### 3.3.4 SW3, SW4, SW5 and SW6 DSP Boot Configurations

SW3, SW4, SW5, and SW6 are four-position DIP switches, which are used for DSP ENDIAN, Boot Device, Boot Configuration, and PCI Express subsystem configuration.

For the details about the DSP Boot modes and their configuration, please refer to the TMS320C6670 Data Manual.

The diagram of the default setting on these switches is shown below:




Figure 3.6: SW3, SW4, SW5, and SW6 default settings

The following table describes the positions and corresponding functions on SW.

Table 3.16: SW3-SW6, DSP Configuration Switch

SW#	Description	Default Value	Function
SW3[1]	ENDIAN	0x1b (OFF)	Device endian mode (LENDIAN). 0 = Device operates in big endian mode <b>1 = Device operates in little endian mode</b>
SW3[4:2]	Boot device Bit[2:0]	0x101b (OFF,ON,OFF)	Boot Device 000b = None 001b = Serial Rapid I/O 010b = SGMII (PA driven from core clk) 011b = SGMII (PA driver from PA clk) 100b = PCI Express <b>101b = I2C</b> 110b = SPI 111b = HyperLink
SW5[1] SW4[4:1]	Parameter Index [4:0] / Boot Mode [7:3]	00000b (ON,ON,ON, ON,ON)	These 5 bits are the Parameter Index when I2C is the boot device. They have other definitions for other boot devices. For the details about the device configuration, For the details about the device configuration, please refer to the <a href="#">TMS320C6670 Data Manual</a> .
SW5[2]	Mode / Boot Mode [8]	0 (ON)	Mode (I2C Boot Device) <b>0</b> = Master <b>1</b> = Slave
SW5[3]	Reserved / Boot Mode [9]	0 (ON)	Bit reserved with I2C Boot Device
SW5[4]	Address / Boot Mode [10]	1 (OFF)	Address (I2C Boot Device) 0 = Boot from address 0x50 <b>1</b> = Boot from address 0x51
SW6[1]	Speed / Boot Mode [11]	0 (ON)	Speed (I2C Boot Device) <b>0</b> = Low speed <b>1</b> = High Speed

SW6[2]	Reserved / Boot Mode [12]	0 (ON)	Bit reserved with I2C Boot Device
SW6[4:3]	PCIESSMODE [1:0]	00b (ON,ON)	PCIe Subsystem mode selection. <b>00b</b> = PCIe in end point mode 01b = PCIe legacy end point (no support for MSI) 10b = PCIe in root complex mode 11b = Reserved

### 3.3.5 SW9, DSP PCIE Enable / User Defined and DSP\_DSPCLKSEL / FPGA\_PACLKSEL Switch Configuration

SW9 is a 4-position DIP switch. The first position is used for enabling the PCI Express Subsystem within the DSP. The second position is undefined by hardware and available for application software use. The third and fourth positions are used by selecting the PLL sources for CORECLK and PASSCLK of the DSP. A diagram of the SW9 switch (with factory default settings) is shown below:




Figure 3.7: SW9 default settings

The following table describes the positions and corresponding functions on SW9.

Table 3.17: SW9, DSP PCIESEN and User Switch /DSPCLKSEL/PACLKSEL

SW9	Description	Default Value	Function
SW9[1]	PCIESEN	0x0b (ON)	PCIe module enable. 0 = PCIe module disabled 1 = PCIe module enabled
SW9[2]	User Switch	0x0b (ON)	Application software defined
SW9[3]	DSPCLKSEL	0x0b (ON)	<b>CORECLKSEL</b> : RFU, Reserved for Future Use
SW9[4]	PACLKSEL	0x0b (ON)	<b>PACLKSEL</b> : RFU, Reserved for Future Use

### 3.4 Test Points

The TMDXEVM6670L EVM Board has 27 test points. The position of each test point is shown in the figures below:




Figure 3.8: TMDXEVM6670L test points on top side




Figure 3.9: TMDXEVM6670L test points on the bottom side

Table 3.18: TMDXEVM6670L EVM Board Test Points

Test Point	Signal
TP7	Reserved for MMC1 pin23
TP8	Reserved for MMC1 pin33
TP9	Reserved for MMC1 pin25
TP5	HyperLink_REFCLKOUTP
TP6	HyperLink_REFCLKOUTN
TP12	DSP_SYSCLKOUT
TP10	Reserved for U12 (FT2232) pin60 (PWREN#)
TP11	Reserved for U12 (FT2232) pin36 (SUSPEND#)
TP4	PHY1 (88E1111) 125MHz clock (default: disable)
TP13	Reserved for FPGA1 (XC3S200AN) pin C12 (+1.8V I/O).
TP14	Reserved for FPGA1 (XC3S200AN) pin A13 (+1.8V I/O).
TP16	Reserved for FPGA1 (XC3S200AN) pin T10 (+3.3V I/O).
TP17	Reserved for FPGA1 (XC3S200AN) pin R11 (+3.3V I/O).
TP18	Reserved for FPGA1 (XC3S200AN) pin T11 (+3.3V I/O).
TP21	Test point for CVDD
TP22	Test point for VCC1V2
TP23	Test point for VCC1V8_AUX
TP24	Test point for VCC2V5
TP25	Test point for VCC1V8
TP26	Test point for VCC0V75
TP27	Test point for VCC3V3_AUX
TP28	Test point for VCC5
TP29	Test point for VCC1V5
TP30	Test point for VCC1V0
TP32	Test point for VCC12
TP31	GND SHORT PAD
TP35	GND SHORT PAD

### 3.5 System LEDs

The TMDXEVM6670L board has 7 LEDs. Their positions on the board are indicated in figure 3.9. The description of each LED is listed in the table below:

Table 3.19: TMDXEVM6670L EVM Board LEDs

LED#	Color	Description
D1	Red	Failure and Out of service status in AMC chassis
D2	Blue	Hot Swap status in AMC chassis
SYSPG_D1	Blue	All Power rails are stable on AMC
FPGA_D1-D4	Blue	Debug LEDs.




Figure 3.10: TMDXEVM6670L EVM Board LEDs

## 4. System Power Requirements

---

This chapter describes the power design of the TMDXEVM6670L board. It contains:

- 4.1 Power Requirements
- 4.2 Power Supply Distribution
- 4.3 Power Supply Boot Sequence

### 4.1 Power Requirements

Note that the power estimates stated in this section are maximum limits used in the design of the EVM. They have margin added to allow the EVM to support early silicon samples that normally have higher power consumption than eventual production units.

The maximum EVM power requirements are estimated to be:

- EVM FPGA – 0.65 W;
- DSP Cooling Fans – 1.2 W (+12 VDC/0.1 A);
- Clock Generators & clock sources – 4.95 W;
- DSP – 14.90 W; [worse case]
  - Core: 13.0 W;
  - Peripherals I/O: 1.90 W;
- DDR3 – 2.63 W;
  - 5 SDRAMs to support 64-bit with ECC of DSP
- Misc – 0.33 W;
- USB – 0.84 W;
- SGMII PHY – 1.14 W;

EVM board total: 32.64 W.

The selected AC/DC 12-V adapter should be rated for a minimum of 36 Watts.

The power planes in TMDXEVM6670L are identified in the following table:

Table 4.1: EVM Voltage Table

Device	Net name	Voltage	Description
Input	3.3V_MP_AMC	+3.3 V	Management Power for MMC
	VCC12	+12 V	Payload Power to AMC
Management	VCC3V3_AUX	+3.3 V	3.3 V Power Rail for all support devices on EVM
	VCC1V2	+1.2 V	1.2 V Power Rail for all support devices on EVM
	VCC1V8_AUX	+1.8V	1.8V Power Rail for all support devices on EVM
TMS320C6670	CVDD	+0.6V~1.10V	DSP Core Power
	VCC1V0	+1.0V	DSP Fixed Core Power
	VCC1V8	+1.8V	DSP I/O power
	VCC1V5	+1.5V	DSP DDR3 and SERDES Power
DDR3 Memory	VCC1V5	+1.5V	DDR3 RAM Power
	VCC0V75	+0.75V	DDR3 RAM Termination Power
NAND Flash	VCC1V8	+1.8V	NAND Flash Power
NOR Flash (SPI)	VCC1V8	+1.8V	SPI NOR Flash Power
CDCE62002	VCC3V3_AUX	+3.3V	Clock Gen Power
CDCE62005	VCC3V3_AUX	+3.3V	Clock Gen Power
PHY (88E111)	VCC2V5	+2.5V	PHY Analog and I/O Power
	VCC1V2	+1.2V	PHY Core Power (instead of 1.0V)
USB Emulator	VCC3V3_AUX	+3.3V	USB Emulation Power (FT2232H)
	VCC1V8_AUX	+1.8V	USB Emulation Power (FT2232H)
MMC (MPS430)	VCC3V3_MP	+3.3V	MMC Power
FPGA	VCC1V2	+1.2V	FPGA Core Power
	VCC3V3_AUX	+3.3V	FPGA I/O Power for +3.3V bank
	VCC1V8_AUX	+1.8V	FPGA I/O Power for +1.8V bank
Misc. Logic	VCC3V3_AUX	+3.3V	Translator and Logic Power
	VCC1V8_AUX	+1.8V	Translator and Logic Power



The following table identifies the expected power requirements for each power plane of the devices on the TMDXEVM6670L EVM.

Table 4.2: Each Current Requirements on each device of EVM board

TMS320C6670	V(V)	I(A)	Qty	Pd (W)	
CVDD (Core)	1.00	9.75	1	9.75	14.88
VCC1V0 (I/O)	1.00	4.52	1	4.52	
VCC1V8(I/O)	1.80	0.116	1	0.21	
VCC1V5(I/O)	1.50	0.266	1	0.40	
DDR3	V(V)	I(A)	Qty	Pd(W)	
VCC1V5	1.50	0.30	5	2.25	2.63
VCC0V75	0.75	0.10	5	0.38	
FPGA	V(V)	I(A)	Qty	Pd(W)	
VCC3V3_AUX	3.30	0.03	1	0.10	0.62
VCC1V2	1.20	0.13	1	0.16	
VCC1V8_AUX	1.80	0.20	1	0.36	
XDS560V2	V(V)	I(A)	Qty	Pd(W)	
VCC5	5.00	1.00	1	5.00	5.99
VCC3V3_AUX	3.30	0.30	1	0.99	
CDCE62005	V(V)	I(A)	Qty	Pd(W)	
VCC3V3_AUX	3.30	0.50	2	3.30	3.30
CDCE62002	V(V)	I(A)	Qty	Pd(W)	
VCC3V3_AUX	3.30	0.50	1	1.65	1.65
PHY (88E1111)	V(V)	I(A)	Qty	Pd(W)	
VCC2V5_AUX	3.30	0.21	1	0.69	1.14
VCC1V2_AUX	1.80	0.25	1	0.45	
FT2232	V(V)	I(A)	Qty	Pd(W)	
VCC3V3_AUX	3.30	0.21	1	0.69	0.84
VCC1V8_AUX	1.80	0.08	1	0.14	
MMC (MSP430)	V(V)	I(A)	Qty	Pd(W)	
VCC3V3_MP	3.30	0.02	1	0.07	0.07

## 4.2 Power Supply Distribution

A high-level block diagram of the power supplies is shown in Figure 4.1 as well as on the schematic.

In Figure 4.1, the Auxiliary power rails are always on after payload power is supplied. These regulators support all control, sequencing, and boot logic. The Auxiliary Power rails contain:

- VCC3V3\_AUX
- VCC1V8\_AUX
- VCC1V2
- VCC5\_AUX

The maximum allowable power is 36 W from the external AC brick supply or from the 8 AMC header pins.




Figure 4.1: All the AMC power supply on TMDXEVM6670L EVM

Individual control for each (remaining) voltage regulator is provided to allow flexibility in how the power planes are sequenced (See section 4.3 for specific details). The goal of all power supply designs is to support a minimum temperature range of 0°C to 45°C.

The TMS320C6670 core power is supplied using a dual digital controller coupled to a high performance FET driver IC. Additional DSP supply voltages are provided by discrete TI Swift power supplies. The TMS320C6670 supports a VID interface to enable Smart-Reflex® power supply control for its primary core logic supply. Refer to the TMS320C6670 Data Manual and other documentation for an explanation of the Smart-Reflex® control.

Figure 4.1 shows that the EVM power supplies are a combination of switching supplies and linear supplies. The linear supplies are used to save space for small loads. The switching supplies are implemented for larger loads. The switching supplies are listed below followed by explanations of critical component selection:


- CVDD (AVS core power for TMS320C6670)
- VCC1V0 (1.0V fixed core power for TMS320C6670)
- VCC3V3\_AUX (3.3V power for peripherals)
- VCC1V5 (1.5V DDR3 power for TMS320C6670 and DDR3 memories)
- VCC5 (5.0V power for the XDS520V2 mezzanine card)

The **CVDD** and **VCC1V0** power rails are regulated by TI Smart-Reflex controller UCD9222 and the synchronous-buck power driver UCD74110 and UCD74106 to supply DSP AVS core and CVDD1 core power.

The **VCC3V3\_AUX** and **VCC1V5** power rails are regulated by two TI 6A Synchronous Step Down SWIFT™ Converters, TPS54620, to supply the peripherals and other power sources and the DSP DDR3 EMIF and DDR3 memory chips respectively.

The **VCC5** power rail is regulated by TI 2A Step Down SWIFT™ DC/DC Converter, TPS54231, to supply the power of the XDS560V2 mezzanine card on TMDXEVM6670L.

The high level diagrams and output components are shown in figure 4.2, figure 4.3, figure 4.4 and figure 4.5 as well as choosing the proper inductors and buck capacitors.



**Inductor for VCC1V0**

L : 0.47 uH

**Output capacitors for VCC1V0**

C : 470uF / 4V x 2 +  
47uF / 6.3V x 2


**Inductor for CVDD**

L : 0.2 uH

**Output capacitors for VCC1V0**

C : 470uF / 4V x 2 +  
47uF / 6.3V x 6

Figure 4.2: The CVDD and VCC1V0 (CVDD1) power design on TMDXEVM6670L EVM



(Over all tolerance is 5% ,DC tolerance is 2.5%) (KIND=0.3)

**Output capacitor Calculation**

$$C_{out} > (2 \times \Delta I_{out}) / (F_{sw} \times \Delta V_{out})$$

$$C_{out} > (2 \times 3) / (840\text{KHz} \times 0.0825)$$

$$C_{out} > (6) / (69300)$$

$$C_{out} > 87\mu\text{F}$$

Reference Capacitor : 100uF

**Inductor Calculation**

$$L = ((V_{in(max)} - V_{out}) / I_{out} \times Kind) \times (V_{out} / (V_{in(max)} \times F_{sw}))$$

$$L = ((12.6 - 3.3) / 3 \times Kind) \times (3.3 / (12 \times 840\text{KHz}))$$


$$L = ((8.7/3 \times 0.3) \times (3.3 / (10.08\text{M})))$$

$$L = (9.67) \times (0.33\mu)$$

$$L \sim 3.2\mu\text{H}$$

Reference Inductor 3.3uH

Figure 4.3: The VCC3\_AUX power design on TMDXEVM6670L EVM



(Over all tolerance is 5% ,DC tolerance is 2.5% )

**Output capacitor Calculation**

$$C_{out} > (2 \times \Delta I_{out}) / (F_{sw} \times \Delta V_{out})$$

$$C_{out} > (2 \times 2.5) / (840\text{KHz} \times 0.0375)$$

$$C_{out} > (5) / (31500)$$

$$C_{out} > 159\mu\text{F}$$

Reference Capacitor : 100uF x 2=200uF

**Inductor Calculation** (KIND=0.3)

$$L = ((V_{in(max)} - V_{out}) / I_{out} \times K_{ind}) \times (V_{out} / (V_{in(max)} \times F_{sw}))$$

$$L = ((12 - 1.5) / 2.5 \times K_{ind}) \times (1.5 / (12 \times 840\text{KHz}))$$


$$L = ((10.5 / 2.5 \times 0.3) \times (1.5 / (10.08\text{M})))$$

$$L = (10.51 / 0.75) \times (0.1488\text{M})$$

$$L = 2.09\mu\text{H}$$

Reference Inductor 3.3uH

Figure 4.4: The VCC1V5 power design on TMDXEVM6670L EVM



**Output capacitor Calculation**

$$C_{o\_min} = 1 / (2 \times \pi \times R_o \times F_{CO\_max})$$

$$C_{out} : 1 / (2 \times 3.14 \times 5 \times 25\text{K})$$

$$C_{out} : 1.3 \mu\text{f}$$

Reference Capacitor : 100uF

**Inductor Calculation** (KIND=0.3)

$$L : ((V_{in(max)} - V_{out}) / I_{out} \times K_{ind}) \times (V_{out} / (V_{in(max)} \times F_{sw}))$$

$$L : ((12.6 - 5) / 1 \times K_{ind}) \times (5 / (12.7 \times 570\text{K}))$$

$$L : ((7.6 / 0.3) \times (5 / (7239\text{K})))$$

$$L : (25.3) \times (0.69\text{M})$$

$$L : 17.5\mu\text{H}$$

Reference Inductor 22uH

Figure 4.5: The VCC5 power design on TMDXEVM6670L EVM

### 4.3 The Power Supply Boot Sequence

Specific power supply and clock timing sequences are identified below. The TMS320C6670 DSP requires specific power up and power down sequencing. Figure 4.6 and Figure 4.7 illustrate the correct boot up and down sequence. Table 4.3 provides the timing details for Figure 4.6 and Figure 4.7.

Refer to the TMS320C6670 DSP Data Manual for confirmation of specific sequencing and timing requirements.

Step	Power rails	Timing	Descriptions
<b>Power-Up</b>			
1	VCC12 (AMC Payload power), VCC3V3_AUX, VCC1V8_AUX VCC1V2 VCC5	Auto	When the 12V power supplied to the TMDXEVM6670L, the 3.3V, 1.8V and 1.2V supplies to the FPGA power will turn on. The 1.8V outputs on the FPGA to the DSP will be locked (held at ground).
2	VCC2V5	10mS	Turn on VCC2V5 after VCC3V3 stable for 10mS.
3	CVDD (DSP AVS core power)	5mS	Enable the CVDD and VCC1V0, the UCD9222 power rail#1 is for CVDD and go first after both of VCC5 and VCC2V5 are stable for 5mS.
4	VCC1V0 (DSP CVDD1 fixed core power)	5mS	Turn on VCC1V0, the UCD222 power rail#2. The VCC1V0 will start the regulating power rail after enable it after 5mS, the start-delay time is set by the UCD9222 configuration file.
5	VCC1V8 (DSP IO power)	5mS	Turn on VCC1V8 after VCC1V0 stable for 5mS.
6	CDCE62005#2/#3 initiations CDCE62002#1 initiations FPGA 1.8V outputs	5mS	Unlock the 1.8V outputs to the DSP from the FPGA and initiate the CDCE62005s and CDCE62002 after VCC1V8 stable for 5mS. De-asserted CDCE62005s and CDCE62002 power down pins (PD#), initial the clock generators.
7	VCC1V5 (DSP DDR3 power)	5mS	Turn on VCC1V5 after initiation of the clock generators for 5mS.
8	VCC0V75	5mS	Turn on VCC0V75 after VCC1V5 stable for 5mS. When VCC1V5 is valid, FPGA will de-assert the power down pin on

			the ICS557-08, the PCIE clock multiplexer. When the VCC0V75 is valid, FPGA will enable the ICS557-08 clock outputs by the OE# pin on it.
9	RESETz Other reset and NMI pins	5mS	De-asserted RESETz and unlock other reset and NMI pins for the DSP after VCC0V75 stable and 3 clock generators' PLLs locked for 5mS. In the meanwhile, the FPGA will driving the boot configurations to the DSP GPIO pins.
10	PORz	5mS	De-asserted PORz after RESETz de-asserted for 5mS.
11	RESETFULLz	5mS	De-asserted RESETFULLz after PORz de-asserted for 5mS.
12	DSP GPIO pins for boot configurations	1mS	Release the DSP GPIO pins after RESETFULLz de-asserted for 1mS
<b>Power-Down</b>			
13	RESETFULLz PORz	0mS	If there is any power failure events or the AMC payload power off, the FPGA will assert the RESETFULLz and PORz signals to the DSP.
14	FPGA 1.8V outputs to DSP CDCE62005 and CDCE62002 PDz pins	5mS	Locked 1.8V output pins on the FPGA and pull the CDCE62005 and CDCE62002 PDz pins to low to disable the DSP clocks.
15	CVDD VCC1V0 VCC1V8 VCC1V5 VCC0V75 VCC2V5 ICS557-08 PD# and OE#	0mS	Turn off all main power rails.

Table 4.3: The power-up and down timing on the TMDXEVM6670L




Figure 4.6: Initial Power-on Sequence Timing Diagram






Figure 4.7: Power Down Sequence Timing Diagram

## 5. TMDXEVM6670L FPGA FUNCTIONAL DESCRIPTION

---

This chapter contains,

- 5.1 FPGA overview
- 5.2 FPGA signals description
- 5.3 Sequence of operation
- 5.4 Reset definition
- 5.5 SPI protocol
- 5.6 CDCE62005 & CDCE62002 Programming Descriptions
- 5.7 FPGA Configuration Registers

### 5.1 FPGA overview

The FPGA (Xilinx XC3S200AN) controls the EVM power sequencing, reset mechanism, DSP boot mode configuration and clock initialization. The FPGA also provides the transformation of TDM Frame Synchronization signal and Reference Clock between the AMC connector and the DSP.

The FPGA also supports 4 user LEDs and 1 user switch through control registers. All the FPGA registers are accessible by the TMS320C6670 DSP.

The key features of the TMDXEVM6670L EVM FPGA are:

- TMDXEVM6670L EVM Power Sequence Control
- TMDXEVM6670L EVM Reset Mechanism Control
- TMDXEVM6670L EVM Clock Generator Initialization and Control
- TMS320C6670 DSP SPI Interface for accessing the FPGA Configurable Registers
- Provides Shadow Registers for TMS320C6670 DSP to Access the Clock Generator Configurations Registers
- Provides Shadow Registers for TMS320C6670 DSP to Access the UCD9222 Devices via the PM Bus (TBD)
- Provides TMS320C6670 DSP Boot Mode Configuration switch settings to DSP
- MMC Reset Events Initiation Interface
- Provides the TCLK transformation from the LVDS format to single ended 1.8V level signal between AMC edge connector and the DSP
- Provide Ethernet PHY Interrupt and Reset Control Interface

- Provides Reset Buttons, User Switches, and Debug LEDs
- FPGA Device and Packaging  
XILINX XC3S200AN FPGA  
256 Ball ftBGA (17x17 mm), 1.0mm pitch

## 5.2 FPGA signals description

This section provides a detailed description of each signal. The signals are arranged in functional groups according to their associated interface. Throughout this manual, a '#' or 'Z' will be used at the end of a signal name to indicate that the active or asserted state occurs when the signal is at a low voltage level.

The following notations are used to describe the signal and type.

I	Input pin
O	Output pin
I/O	Bi-directional pin
Differential	Differential Pair pins
PU	Internal Pull-Up

Table 5.1: TMDXEVM6670L EVM FPGA Pin Description

Pin Name	IO Type	Description
<b>MMC Control :</b>		
MMC_DETECT#	I PU	<b>MMC Detection on the insertion to an AMC Chassis:</b> This signal is an insertion indication from the MMC. The MMC will drive logic low state when the EVM module is inserted into an AMC chassis.
MMC_RESETSTAT#	O	<b>RESETSTAT# state to MMC:</b> The FPGA will drive the same status of the DSP RESETSTAT# to the MMC via this signal.
MMC_POR_IN_AMC#	I PU	<b>MMC POR Request:</b> This signal is used by the MMC to request a Power-on reset sequence to DSP. A logic Low to High transition on this signal will complete the FPGA Full Reset sequence with a specified delay time.
MMC_WR_AMC#	I PU	<b>MMC WARM Request:</b> This signal is used by the MMC to initiate a warm reset request. A logic Low to High transition on this signal will complete the FPGA warm reset sequence with a specified delay time.
MMC_BOOTCOMPLETE	O	<b>BOOTCOMPLETE state to MMC:</b> The FPGA will drive the same status of the DSP BOOTCOMPLETE to the MMC via this signal.

Pin Name	IO Type	Description
<b>Power Sequences Control :</b>		
VCC5_PGOOD	I	<b>5V Voltage Power Good Indication:</b> This signal indicates the 5V power is valid.
VCC2P5_PGOOD	I	<b>2.5V Voltage Power Good Indication:</b> This signal indicates the 2.5V power is valid.
VCC3_AUX_PGOOD	I	<b>3.3V Auxiliary Voltage Power Good Indication:</b> This signal indicates the 3.3V auxiliary power is valid.
VCC0P75_PGOOD	I	<b>0.75V Voltage Power Good Indication:</b> This signal indicates the 0.75V power is valid.
VCC1P5_PGOOD	I	<b>1.5V Voltage Power Good Indication:</b> This signal indicates the 1.5V power is valid.
VCC1P8_PGOOD	I	<b>1.8V Voltage Power Good Indication:</b> This signal indicates the 1.8V power is valid.
SYS_PGOOD	O	<b>System Power Good Indication:</b> This signal is indicated by the FPGA to the system when all the power supplies are valid.
VCC1P8_EN1	O	<b>1.8V Voltage Power Supply Enable:</b> VCC1P8_EN1 is for 1.8V power plane control.
VCC0P75_EN	O	<b>0.75V Voltage Power Supply Enable:</b> VCC0P75_EN is for 0.75V power plane control.
VCC2P5_EN	O	<b>2.5V Voltage Power Supply Enable:</b> VCC2P5_EN is for 2.5V power plane control.
VCC_5V_EN	O	<b>5V Voltage Power Supply Enable:</b> VCC_5V_EN is for 5V power plane control.
VCC1P5_EN	O	<b>1.5V Voltage Power Supply Enable :</b> VCC1P5_EN is for 1.5V power plane control.
<b>CLOCK Configurations:</b>		
CLOCK[1:3]_SSPCS1	O	<b>SPI Chip Select Enable:</b> This signal is connected to the TI CDCE62002 & CDCE62005 CLOCK Generators SPI_LE pin. The falling edge of the SSPCS1 initiates a transfer. If SSPCS1 is high, no data transfer can take place.
CLOCK[1:3]_SSPCK	O	<b>SPI Serial Clock:</b> This signal is connected to the TI CDCE62002 & CDCE62005 CLOCK Generators SPI_CLK pin. The FPGA SPI bus clocks data in and out on the rising edge of SSPCK. Data transitions therefore occur on the falling edge of the clock.
CLOCK[1:3]_SSPSI	O	<b>SPI Serial Data MOSI:</b> This signal is connected to the TI CDCE62002 & CDCE62005 CLOCK Generators MOSI pin. This signal is used for serial data transfers from the master (FPGA) output to the slave (62002)(62005) input.

Pin Name	IO Type	Description
CLOCK[1:3]_SSPSO	I	<b>SPI Serial Data MISO:</b> This signal is connected to the TI CDCE62002 & CDCE62005 CLOCK Generators MISO pin. This signal is used for the serial data transfers from the slave (62002)(62005) output to the master (FPGA) input.
REFCLK[1:3]_PD#	O	<b>TI CDCE62002 / 62005 CLOCK Generator Power Down:</b> The power down pins each place the respective CDCE62002/62005 into the power down state forcing the differential clock output into the high-impedance state.
<b>UCD9222 Interface :</b>		
UCD9222_PG1	I	<b>UCD9222 Power Good Indication for CVDD DSP Core Power:</b> This signal indicates the CVDD DSP core power is valid.
UCD9222_ENA1	O	<b>UCD9222 Enable for CVDD DSP Core Power:</b> UCD9222_ENA1 is for CVDD DSP core power plane control.
UCD9222_PG2	I	<b>UCD9222 Power Good Indication for VCC1V0 DSP Core Power:</b> This signal indicates the VCC1V0 DSP core power is valid.
UCD9222_ENA2	O	<b>UCD9222 Enable for VCC1V0 DSP Core Power:</b> UCD9222_ENA2 is for VCC1V0 DSP core power plane control.
PGUCD9222	I	<b>UCD9222 Power Good Indication:</b> This signal indicates both the CVDD DSP and VCC1V0 DSP core power supplies are valid.
UCD9222_RST#	O	<b>UCD9222 Reset:</b> An active low signal will reset the UCD9222 device.
<b>PM BUS: (RFU)</b>		
PMBUS_CLK	O	<b>PM Bus Clock:</b> The FPGA provides the clock source on the PM bus.
PMBUS_DAT	I/O	<b>PM Bus Data:</b> A PM Bus slave device can receive data provided by the master (FPGA), or it can also provide data to the master (FPGA) via this signal line.
PMBUS_ALT	I	<b>PM Bus Alert:</b> The PM Bus device may notify the host (FPGA) via this signal if a fault or warning is detected.
PMBUS_CTL	O PU	<b>PM Bus Control:</b> This signal is used to turn the device on and off in conjunction with UCD9222_ENA1 / UCD9222_ENA2 pins.
<b>PHY Interface :</b>		
PHY_INT#	I	Interrupt Request from 88E1111 PHY(RFU)

Pin Name	IO Type	Description
PHY_RST#	O	<b>Reset to 88E1111 PHY:</b> This signal is used to reset the 88E1111 PHY device. The PHY_RST# will be asserted during the active DSP_PORZ or DSP_RESETFULLz period. The PHY_RST# logic also can be configured by the DSP accessed register.
<b>DSP SPI :</b>		
DSP_SSPCS1	I	<b>DSP SPI Chip Select 1:</b> This signal is connected to the TMS320C6670 DSP SPISCS1 pin. The falling edge of the SSPCS1 from the DSP will initiate a transfer. If SSPCS1 is high, no data transfer can take place.
DSP_SSCK	I	<b>DSP SPI Serial Clock:</b> This signal is connected to the TMS320C6670 DSP SPICLK pin. The FPGA SPI bus clocks data in on the falling edge of SSCK. Data transitions therefore occur on the rising edge of the clock.
DSP_SSPMISO	O	<b>DSP SPI Serial Data MISO:</b> This signal is connected to the TMS320C6670 DSP SPIDIN pin. This signal is used for serial data transfers from the slave (FPGA) output to the master (DSP) input in the DSP_SSPCS1 asserted period.
DSP_SSPMOSI	I	<b>DSP SPI Serial Data MOSI:</b> This signal is connected to the DSP SPIDOUT pin. This signal is used for serial data transfers from the master (DSP) output to the slave (FPGA) input.
<b>RESET Buttons and Requests :</b>		
FULL_RESET	I	<b>Full Reset Button Input:</b> This button input is used to initiate a Full Reset event.
WARM_RESET	I	<b>Warm Reset Button Input:</b> This button input is used to initiate a Warm Reset event.
COLD_RESET (RFU)	I	<b>Cold Reset Button Input :</b> Reserved for Future Use (RFU).
FPGA_JTAG_RST# (RFU)	I	<b>FPGA JTAG Reset Input :</b> Reserved for Future Use (RFU).
TRGRSTZ	I	<b>Reset Request from the DSP Emulator Header:</b> A warm Reset sequence will be initiated if an active TRGRSTZ event is recognized by the FPGA.
<b>DSP Boot &amp; Device configurations :</b>		
BM_GPIO[0: 15]	I	<b>DSP Boot Mode Strap Configuration:</b> These switch inputs are used to drive the DSP boot mode configuration during the EVM power up period.

Pin Name	IO Type	Description
DSP_GPIO[0: 15]	I/O	<b>DSP GPIO:</b> In normal operation mode, these signals are not driven by the FPGA so that the DSP can use them as GPIO pins. During the EVM Power-on or during the RESETFULLz asserted period, the FPGA will output the BM_GPIO switch values to the DSP on these pins so the DSP can latch the boot mode configuration.
<b>DSP RESET &amp; Interrupts Control :</b>		
DSP_CORESEL[0:2]	O	<b>DSP Core Selection Bit:</b> The default value is 0000b and Register bits define the state of these pins..
DSP_PACLKSEL	O	<b>DSP PACLKSEL:</b> This pin is used for the DSP PASS clock selection setting. The logic of this signal is derived from the BM_GPIO[13:11] state or configured by the FPGA registers.
FPGA_DSPCLKSEL	O	<b>CORECLKSEL :</b> RFU, Reserved for Future Use
FPGA_EXTFRAMEEVENT	I	<b>EXTFRAMEEVENT :</b> RFU, Reserved for Future Use
DSP_LRESETNMIENZ	O	<b>Latch Enable for DSP Local Reset and NMI Inputs:</b> The default value is 1b and a register bit defines the state of this pin.
DSP_NMIZ	O	<b>DSP NMI.</b> The default value is 1b and unlocked a register bit defines the state of this pin.
DSP_LRESETZ	O	<b>DSP Local Reset.</b> The default value is 1b and a register bit defines the state of this pin.
DSP_HOUT	I	<b>DSP HOUT</b>
DSP_BOOTCOMPLETE	I	<b>DSP Boot Complete Indication</b>
DSP_SYCLKOUT	I	<b>DSP System Clock Output</b>
DSP_PORZ	O	<b>DSP Power-on Reset</b>
DSP_RESETFULLz	O	<b>DSP Full Reset.</b>
DSP_RESETZ	O	<b>DSP Reset</b>
<b>FPGA Storage (RFU):</b>		
FPGA_SPI_CS#	O	<b>FPGA SPI Chip Select:</b> (RFU)
FPGA_SPI_SI	O	<b>FPGA SPI Serial Data MOSI:</b> (RFU)
FPGA_SPI_SCK	O	<b>FPGA SPI Clock Output:</b> (RFU)
FPGA_SPI_SO	I	<b>FPGA SPI Serial Data MISO:</b> (RFU)
<b>Telecom CLK :</b>		
TCLKA[p/n]	I, Diff	<b>TCLKA Differential Clock Input Pair</b> Telecom reference clock A from the AMC backplane.

Pin Name	IO Type	Description
TCLKB[p/n]	I, Diff	<b>TCLKB Differential Clock Input Pair (RFU)</b> Telecom reference clock B from the AMC backplane.
TCLKC[p/n] DSP_TIMIO_AMC / DSP_TIMOO_AMC	I, O, Diff	<b>TCLKC Differential Clock Input Pair</b> Telecom reference clock C from the AMC backplane. On Rev 3.0 EVM, the TCLKCp pin is used as a timer output for the DSP timer 0; the TCLKCn is used as a timer input for the DSP timer 0.
TCLKD[p/n]	I, Diff	<b>TCLKD Differential Clock Input Pair (RFU)</b> Telecom reference clock D from the AMC backplane.
<b>DEBUG LED:</b>		
DEBUG_LED[1:4]	O	<b>Debug LED:</b> The LEDs are used for debugging purposes only. It can be configured by the registers in the FPGA.
<b>Miscellaneous :</b>		
MAIN_48MHZ_CLK_R	I	<b>FPGA Main Clock Source:</b> A 48 MHz clock is used as the FPGA main clock source.
DSP_TIMIO	O	<b>DSP Time 0 Clock :</b> The FPGA provides the clock to DSP time 0. During the EVM power on or PORZ/RESETFULLZ asserted period, the FPGA will drive the PCIESSEN switch state to DSP for the boot configuration strapping. The FPGA drives 24MHz to DSP_TIMIO after the DSP Boot Configuration Strapping completed
DSP_TIMI1	O	<b>DSP Timer 1 Clock:</b> The FPGA provides the clock to DSP time 1. The FPGA drives 24MHz to DSP_TIMI1 after the DSP Boot Configuration Strapping completed.
DSP_TIMIO_80PIN	I	<b>Timer Input from 80-pin expansion header:</b> The DSP_TIMIO_80PIN is a timer signal from 80-pin expansion header, it's a wire-or logic with DSP_TIMIO_AMC (TCLKCn) pin for the DSP_TIMIO pin to the DSP. Please note that either DSP_TIMIO_AMC or DSP_TIMIO_80PIN could be get into the FPGA for DSP_TIMIO pin.
PCA9306_EN (RFU)	O	<b>PCA9306 Enable:</b> This signal is used to enable the DSP Smart Reflex I2C buffer function.
NAND_WP#	O	<b>NAND Flash Write Protect:</b> This signal is used to control the NAND flash write-protect function.
NOR_WP#	O	<b>NOR Flash Write Protect:</b> This signal is used to control the NOR flash write-protect function.



Pin Name	IO Type	Description
EEPROM_WP	O	<b>EEPROM Write Protect:</b> This signal is used to control the EEPROM write-protect function.
PCIESSEN	I	<b>PCI Subsystem Enable:</b> This is used for the PCIESSEN switch input.
USER_DEFINE	I	<b>User Defined Switch:</b> This is reserved for the user defined switch input.
ICS557_SEL	O	<b>PCI clock multiplexor inputs selection:</b> This pin is controlled by the register to select PCIe reference clock from the CDCE62005 or the AMC edge connector. The default is from the CDCE62005.
ICS557_PD#	O	<b>PCI clock multiplexor Power Down:</b> This pin is used to control the ICS557-08 PD# pin, it's de-asserted after VCC1V5 valid.
ICS557_OE	O	<b>PCI clock multiplexor output enable:</b> This pin enables the output of the ICS557-08.
VID_OE#	O	<b>Smart-Reflex VID Enable:</b> This pin enables the output of the Smart-Reflex VID from the DSP to the UCD9222.
<b>FPGA JTAG TAP Control Port:</b>		
JTAG_FPGA_TCK	I	<b>FPGA JTAG Clock Input</b>
JTAG_FPGA_TDI	I	<b>FPGA JTAG Data Input</b>
JTAG_FPGA_TDO	O	<b>FPGA JTAG Data Output</b>
JTAG_FPGA_TMS	I	<b>FPGA JTAG Mode Select Input</b>
JTAG_FPGA_RST#	I	<b>FPGA JTAG Reset (RFU)</b>

### 5.3 Sequence of operation

This section describes the FPGA sequence of operation on the EVM. It contains:

- 5.3.1 Power-on Sequence
- 5.3.2 Power down Sequence
- 5.3.3 Boot Configuration Timing
- 5.3.4 Boot Configuration Forced in I2C Boot

#### 5.3.1 Power-on Sequence

The following section provides details of the FPGA Power-on sequence of operation.

1. After applying the +12V from either AMC edge connector or the DC-IN connector, the Point of Load supplies (POLs) of VCC3V3\_AUX, VCC1V8\_AUX and VCC1V2 rail on the

EVM start automatically. The FPGA begins for the Power-on sequence of operation when VCC3\_AUX\_PGOOD asserted.

2. The 5V power is enabled first by the FPGA, then it waits for 10 ms and then it enables the 2.5V power rail.
3. Once the 5V and 2.5V voltages (VCC5\_PGOOD and VCC2P5\_PGOOD) are valid, wait for 5 ms, the FPGA asserts the PMBUS\_CTL, UCD9222\_ENA1 and UCD9222\_ENA2 signals simultaneously to enable the CVDD and VCC1V0 DSP core power. The UCD9222 configuration begins ramping CVDD immediately and it waits 5ms before it begins ramping VCC1V0.
4. After both the UCD9222\_PG1 and UCD9222\_PG2 are valid, wait for 5 ms, the FPGA enables the 1.8V power.
5. After the 1.8V voltage (VCC1P8\_PGOOD) is valid, wait for 5 ms, the FPGA initializes the CDCE62005 clock generator#2 and CDCE62005 clock generator#3. Wait for 1 ms after the PLL\_LOCK pins asserted on CDCE62005 clock generator#2 and generator#3, then the FPGA initializes CDCE62002 clock generator#1. Wait for 1 ms after initializations of CDCE62002, the FPGA enables the 1.5V power controller.
6. Wait for 5 ms after the 1.5V power rail valid (VCC1V5\_PGOOD asserted), the FPGA enables the 0.75V power, level translators (I/O pins for C6670) and ICS557-08, the PCIe clock multiplexor.
7. Wait for 5 ms after the 0.75V voltage valid (VCC0V75\_PGOOD asserted), the FPGA removes the states of DSP\_RESETz, DSP\_LRESETz and other I/O pins of C6670 **except DSP\_PORz and DSP\_RESETFULLz**.
8. Wait for 5ms after de-asserting the DSP\_RESETz, DSP\_LRESETz and other I/O pins of C6670, the FPGA checks the PLL locked bits in three clock generators to make sure all clock outputs are stable, If all PLL locked bits are set, there are some tasks the FPGA will do.
  - 8.1 The FPGA de-asserts the DSP\_PORz and keeps the DSP\_RESETFULLz asserted.
  - 8.2 Wait for another 5 ms, the FPGA de-asserts the DSP\_RESETFULLz.
  - 8.3 The FPGA drives the GPIO pins for the DSP boot configuration from the settings of the BM\_GPIO switches during the period starting when VCC0P75\_PGOOD becomes valid until 1ms after RESETSTAT# becomes inactive.
  - 8.4 The FPGA also drives DSP\_TIMIO based on the PCIESSEN switch setting to enable / disable PCIe subsystem of the DSP during the time of the boot configurations.
9. The EVM Power-on sequence is completed if DSP\_RESETSTAT# de-asserted after the DSP\_RESETFULLz removed.
10. The LEDs on the board can be checked to validate successful power-up. These also indicate the power-up state if the board fails to start-up and also indicates failure if a supply fault is detected after a completed start-up.
  - 10.1 After the Power-up sequence, the FPGA lights the Power Good LED to indicate that all power rails are valid and all LVDS clock outputs from the clock generators are available.
  - 10.2 During the Power-on period, the FPGA reports the sequencing "state" and

then holds the current value if the sequence stalls before completion. This will be because one of the power rails did not power-up properly or one of the clocks cannot lock after being enabled.

10.3 If a power failure is detected after a proper and completed power-up sequence; the FPGA turns off the DSP power rails, the clock outputs, the Power Good LED and flashes the FPGA\_D[1:4] LEDs. This will prevent damage to the DSP. The FPGA does not control the power rails of VCC1V2, VCC1V8\_AUX, VCC3V3 and VCC5 because they are for the FPGA and support circuitry and the XDS560V2 mezzanine card.

Below table shows the power states of the indicators during EVM power-on.

Table 5.2: The LED states for Power-on Sequence

LED4	LED3	LED2	LED1	SysPG	State	Note	
@	@	@	@	@	Idle	System Ready for Power On	Power Up
@	@	@	@	@	V2P5	Enable 5V and 2.5V; Check 5V & 2.5V power-good	Power Up
@	@	@	@	@	PMBS	Enable UCD9222-enable1	Power Up
@	@	@	@	@	PMB2	Enable UCD9222-enable2; Check UCD9222_pg1, UCD9222_pg2 and pgUCD9222	Power Up
@	@	@	@	@	V1P8	Enable 1.8V; Check 1.8V power-good; 62002 CLK1 , 62005 CLK2 & CLK3 initialization	Power Up
@	@	@	@	@	V1P5	Enable 1.5V; Check 1.5V power-good	Power Up
@	@	@	@	@	V075	Enable 0.75V; Check 0.75V power-good	Power Up
@	@	@	@	@	CLKG	De-assert RESET#; Check62002 CLK1 PLL Lock, 62005 CLK2 & CLK3 PLL Lock	Power Up
@	@	@	@	@	PORWR	De-assert POR#	Power Up
@	@	@	@	@	WAIT	De-assert RESETFULL#; Check RESESTAT# de-assertion	Power Up
@	@	@	@	@	ON	Power Up Sequence completed; LEDs will changed to FPGA register set value	ON
@	@	@	@	@	ON	Default FPGA register( 08h ) value = "0000"; @ = '0', @ = '1'	ON
%	%	%	%	@	ON	The % reflects the FPGA register (08h) value; R/W accessible by the DSP through the DSP-FPGA SPI interface	ON

Below table shows the power states of the indicators after a proper and completed power-up sequence.

Table 5.3: The LED states for Power Failure

LED4	LED3	LED2	LED1	SysPG	State	Note	
@	@	PGS1	PGS0	@	Power Fail	PGS0 : Last recorded "ucd9222_pg1" status before the power failure occurred PGS1 : Last recorded "ucd9222_pg2" status before the power failure occurred PGSx @ means power good status is '1'; PGSx @ means power good status is '0'.	Power Fail
@	@	PGS3	PGS2	@	Power Fail	PGS2 : Last recorded "pgucd9222" status before the power failure occurred PGS3 : Last recorded 0.75v_PG status before the power failure occurred PGSx @ means power good status is '1'; PGSx @ means power good status is '0'.	Power Fail
@	@	PGS5	PGS4	@	Power Fail	PGS4 : Last recorded 1.5v_PG" status before the power failure occurred PGS5 : Last recorded 1.8v_PG status before the power failure occurred PGSx @ means power good status is '1'; PGSx @ means power good status is '0'.	Power Fail
@	@	PGS7	PGS6	@	Power Fail	PGS6 : Last recorded 2.5v_PG" status before the power failure occurred PGS7 : Last recorded 5v_PG status before the power failure occurred PGSx @ means power good status is '1'; PGSx @ means power good status is '0'.	Power Fail
*	*	*	*	@		LED2 & LED1 will be function as a free-run counter LED3 = FPGA FW Update SPI CLK LED4 = FPGA FW Update SPI CS#	FPGA Update

### 5.3.2 Power Off Sequence

Following section provides details of FPGA power off sequence of operation.

1. Once the system powers on, any power failure events (any one of power good signals de-asserted) will trigger the FPGA to proceed to the power off sequence.
2. Once any de-asserted Power Good signals have been detected by the FPGA, the FPGA will assert the DSP\_PORz to DSP immediately.
3. Wait for 5 ms, the FPGA will disable all the system power rails , assert all the other DSP resets to DSP, lock the +1.8V output pins from the FPGA to the DSP and also assert power down signals to the CDCE62005 and the CDCE62002 clock generators.
4. FPGA remains in the power failure state until main 12V power is removed and restored.

### 5.3.3 Boot Configuration Timing

The boot configuration timing of the power-up and the RESETFULLz event are shown below.




Figure: 5-1 Power-on Reset Boot Configuration Timing




Figure: 5-2 Reset-Full Switch/Trigger Boot Configuration Timing

### 5.3.4 Boot Configuration Forced in I2C Boot

Note: This workaround is only needed with PG1.0 samples of the TMS320C6670 DSP.

For reliable PLL operation at boot-up, the FPGA will force the DSP to boot from the I2C by providing the boot configuration value as 0x0405 on the boot mode pins [12:0]. After the code in the I2C EEPROM executes to initialize the PLLs, it will read the true values on the DIP switches from the registers in the FPGA and then boot as if the normal boot sequence had occurred.

The exception for the forced I2C boot is the emulation boot. The FPGA will not perform the I2C boot configuration override when the DIP switches have the following configuration: BOOTMODE[2:0] (GPIO[3:1]) = [000] and BOOTMODE[5:4] (GPIO[6:5]) = [00]. Therefore, the additional logic of the FPGA will allow the emulation boot to latch directly from the DIP switches.

## 5.4 Reset definition

### 5.4.1 Reset Behavior

- **Power-on:** The Power-on behavior includes initiating and sequencing the power sources, clock sources and then DSP startup. Please refer to the section 5.5.1 for detailed sequence and operations.
- **Full Reset:** The RESETFULLz is asserted low to the DSP. This causes RESETSTAT# to go low which triggers the boot configuration to be driven from the FPGA. Reset to the Marvell PHY is also asserted. POR# and RESET# to the DSP remain high. The power supplies and clocks operate without interruption. Please refer to the section 5.5.3 for detailed timing diagrams.
- **Warm Reset:** The RESETz is asserted low to the DSP. The PORz and RESETFULLz to the DSP remain high. The power supplies and clocks operate without interruption.

### 5.4.2 Reset Switches and Triggers

- **FULL\_RESET (RST\_FULL1)** – a logic low state with a low to high transition will trigger a Full Reset behavior event.

When the push button switch RST\_FULL1 is pressed, FPGA on EVM will assert DSP's RESETFULL# input to issue a total reset of the DSP, everything on the DSP will be reset to its default state in response to this event, boot configurations will be latched and the ROM boot process will be initiated.

This is equivalent to a power cycle of the board but POR and will have following effects:

- \* Reset DSP

- \* Reset Gigabit Ethernet PHY
- \* Reload boot parameters.
- \* Protect the contents in the I2C EEPROM, NAND flash and SPI NOR flash.
- **WARM\_RESET** (RST\_WARM1) – a logic low state with a low to high transition will trigger a warm reset behavior event.

When the push button Switch RST\_WARM1 is pressed, FPGA will assert a DSP RESET# input, which will reset the DSP. Software can program this to be either hard or soft. Hard reset is the default which resets almost everything. Soft Reset will behave like Hard Reset except that PCIe MMRs, EMIF16 MMRs, DDR3 EMIF MMRs, and External Memory contents are retained.

Boot configurations are not latched by Warm Reset. Also, Warm Reset will not reset blocks supporting Reset Isolation when they are appropriately configured previously by application software. Warm Reset must be used to wake from low-power sleep and hibernation modes.

In the case of a Soft Reset, the clock logic or the power control logic of the peripherals are not affected, and, therefore, the enabled/disabled state of the peripherals is not affected. The following external memory contents are maintained

During a Soft Reset:

- **DDR3 MMRs:** The DDR3 Memory Controller registers are *not* reset. In addition, the DDR3 SDRAM memory content is retained if the user places the DDR3 SDRAM in self-refresh mode before invoking the soft reset.
- **PCIe MMRs:** The contents of the memory connected to the EMIFA are retained. The EMIFA registers are *not* reset.
- **COLD\_RESET** (RST\_COLD1) – not used in current implementation.
- **MMC\_POR\_IN\_AMC#** - a logic low state with a low to high transition will trigger a Full Reset behavior event.
- **MMC\_WR\_AMC#** - a logic low state with a low to high transition will trigger a warm reset behavior event.
- **TRGRSTz** - a logic low state with a low to high transition on the Target Reset signal from emulation header that will trigger a warm reset behavior event.
- **FPGA\_JTAG\_RST#** - not used in current implementation.

## 5.5 SPI protocol

This section describes the FPGA SPI bus protocol design specification for interfacing with TMS320C6670 DSP and CDCE62005 clock generators. It contains:

- 5.5.1 The FPGA-DSP SPI Protocol
- 5.5.2 The FPGA-CEDC62005(Clock Generator) SPI Protocol
- 5.5.3 The FPGA- programming CDCE62005 / 62002 by the DSP
- 5.5.4 CDCE62005 / 62002 programming sequences on the FPGA
- 5.5.5 CDCE62005 / 62002 default values on the EVM

### 5.5.1 The FPGA-DSP SPI Protocol

The FPGA supports the simple write and read commands for the TMS320C6670 DSP to access the FPGA configuration registers through the SPI interface. The FPGA SPI bus clocks data in on the falling edge of DSP SPI Clock. Data transitions therefore occur on the rising edge of the clock.

The figures below illustrate the DSP to FPGA SPI write operation.




Figure 5-3: The SPI access from the TMS320C6670 to the FPGA (WRITE / high level)






Figure 5-4: The SPI access form the TMS320C6670 to the FPGA (WRITE)

The figures below illustrate the DSP to FPGA SPI read operation.




Figure 5-5: The SPI access form the TMS320C6670 to the FPGA (READ / high level)




Figure 5-6: The SPI access form the TMS320C6670 to the FPGA (READ)

### 5.5.2 The FPGA- CDCE62005 / CDCE62002 (Clock Generator) SPI Protocol

The FPGA-Clock Generator SPI interface protocol is compatible to CDCE62005 SPI. The FPGA SPI bus clocks data in on the rising edge of DSP SPI Clock. Data transitions therefore occur on the falling edge of the clock.

The figure below illustrates a FPGA to CDCE62005 SPI write operation.




Figure 5-7: The SPI access form the FPGA to the CDCE62005 (WRITE)

The figure below illustrates a FPGA to CDCE62005 SPI read operation.




Figure 5-8: The SPI access form the FPGA to the CDCE62005 (READ)

### 5.5.3 The FPGA- programming CDCE62005 / 62002 by the DSP

This section describes how to configure the CDCE62005 and CDCE62002 clock generators by the DSP via the FPGA with the SPI interface.

- How to configure CDCE62005/62002 for the clock outputs:

Programming sequence of CDCE62005 / 62002 via the FPGA by the DSP is setting the desire values to the relevant offsets on the FPGA for the Register[0:7] of CDCE62005 or the Register[0:2] of CDCE62002 and issues a “start command (send)” by offset 0x10h on the FPGA to conduct programming sequences for CDCE62005/62002.

There are eight and three registers (Register[0:7] and Register[0:2]) mapping to the registers of CDCE62005 and CDCE62002 respectively by the same offsets of CLK#2, CLK3 and CLK1 on the FPGA. Configuring the Clock Generator#2 (CDCE62005) by the DSP is described as below for example.

The CLK#2 offset on the FPGA are 0x17h (MSB) to 0x14h (LSB), they are including 28-bit data field and 4-bit addr. Field as the same of CDCE62005, user can refer to CDCE62005 specification on TI website for the configuration details.

Offset	Register definitions	Type	Default
0x10h	CLK-GEN 2 Control Register	R/W	0x00h
0x11h	CLK-GEN 2 Interface Clock Setting	R/W	0x03h
0x14h	CLK-GEN 2 Command Byte 0	R/W	0x00h
0x15h	CLK-GEN 2 Command Byte 1	R/W	0x00h
0x16h	CLK-GEN 2 Command Byte 2	R/W	0x00h
0x17h	CLK-GEN 2 Command Byte 3	R/W	0x00h
0x18h	CLK-GEN 2 Read Data Byte 0	RO	0x00h
0x19h	CLK-GEN 2 Read Data Byte 1	RO	0x00h
0x1Ah	CLK-GEN 2 Read Data Byte 2	RO	0x00h
0x1Bh	CLK-GEN 2 Read Data Byte 3	RO	0x00h

1. The DSP must set the address number to the offset **0x14h** of the FPGA first to indicate the bank for the corresponding register of CDCE62005. After that, the DSP can set the data to the offset **0x17h, 0x16h, 0x15h** and **0x14h** on the FPGA in sequence for the corresponding register on CDCE62005.

e.g.: User wants to write the 0xEB860300h to CDCE62005 Register 0 and 0x69860314h to CDCE62005 Register 4 on CLK-GEN#2 (CLK2 in the EVM schematics).

- a. Check the bits 0 of 'Busy Status' on offset 0x10h to make sure the last progress have been finished.
  - b. Set address 0x00h to the offset 0x14h, the last 4-bit were set for the Register 0;
  - c. Set data 0xEBh, 0x86h, 0x03h and 0x00h to the offset 0x17h, 0x16h, 0x15h and 0x14h respectively for the new configurations of the clock output0;
  - d. Set address 0x04h to the offset 0x14h, the last 4-bit were set for the Register 4;
  - e. Set data 0x69h, 0x86h, 0x03h and 0x14h to the offset 0x17h, 0x16h, 0x15h and 0x14h respectively for the new configurations of the clock output4;
  - f. The Register 0 and Register 4 on the FPGA for CLK-GEN#2 are updated by the DSP.
  - g. Please note that the default values in the Register[0:7] are the same of values initialized during power-on phase.
2. The DSP sets offset 0x10h bit 0 on the FPGA to upload the configurations to CDCE62005 (CLK-GEN#2).
    - a. The offset 0x10h bit 0 on the FPGA is "initiate/start the data transfer" bit. The FPGA will program the CDCE62005 by the values of the Register[0:7] inside the FPGA via the SPI interface if this bit is set ('1').
    - b. If any of reset events needed after re-programming the CLK GEN, please set the FPGA offset 0x10h register bits 2, 3, or(and) 4 for DSP\_PORz, DSP\_RESETFULLz

or RESETz. The FPGA will issue the reset events based on the offset 0x10h bit[2:4] after finished CDCE62005 programming.

- c. The DSP could check if the programming process finished by the offset 0x10h bit1 of 'Busy State'. The '1' on the offset 0x10h bit1 indicates that the FPGA is programming of CDCE62005.
- d. Please note that the DSP is not allowed to start another programming event on the clock generator while its 'Busy State' at '1'.

● How to read the Register settings on CDCE62005/62002:

The FPGA uses 0x8Eh to be a 'read command' on offset 0x14h low 4-bit and the value of 0x0h to 0x8h to indicate the 'Register number of CDCE62005' on offset 0x14h high 4-bit, the allowed value are between 0 to 8.

Reading the value of Register8 on CLK-GEN#2 by the DSP is shown as below for example. The Register8 on CDCE62005 indicates the status of clock synthesizer. Please note that the offset 0x15h, 0x16h and 0x17h need to be clean to zero before send a reading command.

Set 0x8Eh to FPGA offset 0x14h first and clear the offset 0x15h, 0x16h and 0x17h and then issue a start(send) command to the SPI bus. The CDCE62005 data could be read through the FPGA offset 0x1Bh~0x18h registers once the SPI protocol is completed.

The detail steps are :

- a. The DSP sets value of 0x8Eh to the FPGA offset 0x14h register (0x8h -> Register8; 0xEh -> reading);
- b. The DSP clears the FPGA offset 0x15h, 0x16h, and 0x17h registers by 0x00h;
- c. The DSP sets 0x01h to the FPGA offset 10h register (issue the SPI protocol),

The bit 0 of the offset 0x10h register means "initiate/start the data transfer". The data field on the offset 0x17h-0x14h registers will be sent to the 2nd Clock Generator CDCE62005 via the SPI interface to indicate the reading register number if this bit is set to '1'.);

- d. DSP checks the FPGA offset 0x10h register bit 1;

The the FPGA offset 0x10h register bit1 means "Busy status" and it is used to indicate the CDCE62005 SPI bus status. The SPI bus is busy and a SPI command is processing while this bit is read as '1'.

If the FPGA offset 0x10h register bit1 is '0', the related register value of CDCE62005 has ready been read out and stored on the offset 0x1Bh to 0x18h registers of the FPGA.

- e. The DSP could read the CDCE62005 register 8 (32 SPI bits = 28 data field bits + 4 address field bits ) value through the FPGA offset 0x1Bh~0x18h registers.
- f. DSP would be allowed to issue the next CDCE62005 SPI command.

### 5.5.4 CDCE62005 / 62002 programming sequences on the FPGA

This section describes that FPGA programming CDCE62002/62005 sequences.

- Programming Sequences of CDCE62002 after the DSP's configured the settings and issued a 'send command' through the FPGA:
  - a. The FPGA initializes and programs all data into CDCE62002 registers;
  - b. Wait for 2mS after programming finished;
  - c. The FPGA does the VCO re-calibration for correct outputs on CDCE62002;
    - Assert CDCE62002 Register#2 bit 13 (CALRESET, SPI bit 17), "0->1";
    - The FPGA resets the PLLRESET on CDCE62002, toggle CDCE62002 Register 2 bit 20 (PLLRESET, SPI bit 24) "1->0->1";
  - d. Wait for 100uS for the calibration time of CDCE62002;
  - e. Toggle CDCE62002 Register 2 SPI bit 8 (SYNCz, SPI bit 12) "1->0->1" to synchronize the output dividers.
  
- CDCE62005 Programming Sequence
  - a. The FPGA initializes and programs all data into CDCE62005 registers;
  - b. Wait for 2ms after the initialization and programming have been completed;
  - c. Set the CDCE62005 Register 6 bit 27 (ENCAL\_MODE, SPI bit 31) by '1' for manual mode of PLL calibration;
  - d. Toggle CDCE62005 Register #6 SPI bit 26 (ENCAL) '1-0-1'.

### 5.5.5 CDCE62005 / 62002 default value on the EVM

The below tables show the default configurations inside the static RAM of CDCE62005 and CDCE62002. The FPGA programs and completes the configurations on CDCE62005 and CDCE62002 before RESETz de-asserted.

Table 5.4: CLK1, CDCE62002 Register configurations

Register NO.	Programming value
Register 0	1030_0050(H)
Register 1	838F_00E1(H)
Register 2	2100_3DE2(H)

Table 5.5: CLK2, CDCE62005 Register configurations

Register NO.	Programming value
Register 0	EB86_0300(H)
Register 1	EB80_0321(H)
Register 2	EB80_0322(H)
Register 3	EB40_0103(H)

Register 4	6986_0314(H)
Register 5	1024_0BE5(H)
Register 6	84BE_19C6(H)
Register 7	BD00_37F7(H)

Table 5.6: CLK3, CDCE62005 Register configurations

Register NO.	Programming value
Register 0	EB86_0320(H)
Register 1	EB86_0301(H)
Register 2	EB0E_0302(H)
Register 3	EB86_0303(H)
Register 4	6884_0314(H)
Register 5	3810_0BE5(H)
Register 6	84BE_09A6(H)
Register 7	FD00_37F7(H)

## 5.6 FPGA Configuration Registers

The TMS320C6670 DSP communicates with the FPGA configuration registers through the SPI interface. These registers are addressed by the memory mapped location and defined by the DSP SPI chip enable setting. The following tables list the FPGA configuration registers and the respective descriptions.

The TMS320C6670 DSP communicates with the FPGA configuration registers through the SPI interface. These registers are addressed by the memory mapped location and defined by the DSP SPI chip enable setting. The following tables list the FPGA configuration registers and the respective descriptions.

Table 5.7: TMDXEVM6670L EVM FPGA Memory Map

Memory Map Base Address	Memory Map Offset Address	Memory
<b>DSP SPI Chip Select 1</b> 0x20BF0000-0x20BF03FF (TMS320C6670 DSP SPI Memory Map Address)	0x00-0x4F	Configuration Registers

## 5.6.1 FPGA Configuration Registers Summary

Table 5.6: FPGA Configuration Registers Summary

Address Offset	Definition	Attribute (R/W) (RO: Read-Only)	Default Value
00h	FPGA Device ID (Low Byte)	RO	05h
01h	FPGA Device ID (High Byte)	RO	80h
02h	FPGA Revision ID (Low Byte)	RO	**
03h	FPGA Revision ID (High Byte)	RO	00h*
04h	BM GPI Status (Low Byte)	RO	----
05h	BM GPI Status (High Byte)	RO	----
06h	DSP GPI Status (Low Byte)	RO	----
07h	DSP GPI status (High Byte)	RO	----
08h	Debug LED	R/W	00h
09h	MMC Control	RO	----
0Ah	PHY Control	R/W	03h
0Bh	Reset Buttons Status	RO	00h
0Ch	Miscellaneous - 1	R/W	1Ch
0Dh	Miscellaneous - 2	RO	--
0Eh	FPGA FW Update SPI Interface Control Register	R/W	00h
0Fh	Scratch Register	R/W	00h
10h	CLK-GEN 2 Control Register	R/W	00h
11h	CLK-GEN 2 Interface Clock Setting	R/W	03h
13h~12h	Reserved		0s
14h	CLK-GEN 2 Command Byte 0	R/W	00h
15h	CLK-GEN 2 Command Byte 1	R/W	00h
16h	CLK-GEN 2 Command Byte 2	R/W	00h
17h	CLK-GEN 2 Command Byte 3	R/W	00h
18h	CLK-GEN 2 Read Data Byte 0	RO	00h
19h	CLK-GEN 2 Read Data Byte 1	RO	00h
1Ah	CLK-GEN 2 Read Data Byte 2	RO	00h
1Bh	CLK-GEN 2 Read Data Byte 3	RO	00h
1Fh~1Ch	Reserved		0s
20h	CLK-GEN 3 Control Register	R/W	00h
21h	CLK-GEN 3 Interface Clock Setting	R/W	03h
23h~22h	Reserved		0s
24h	CLK-GEN 3 Command Byte 0	R/W	00h
25h	CLK-GEN 3 Command Byte 1	R/W	00h
26h	CLK-GEN 3 Command Byte 2	R/W	00h
27h	CLK-GEN 3 Command Byte 3	R/W	00h
28h	CLK-GEN 3 Read Data Byte 0	RO	00h
29h	CLK-GEN 3 Read Data Byte 1	RO	00h

Address Offset	Definition	Attribute (R/W) (RO: Read-Only)	Default Value
2Ah	CLK-GEN 3 Read Data Byte 2	RO	00h
2Bh	CLK-GEN 3 Read Data Byte 3	RO	00h
2Fh~2Ch	Reserved		0s
3Fh~30h	PM Bus (RFU)	R/W	0s
40h	CLK-GEN 1 Control Register	R/W	00h
41h	CLK-GEN 1 Interface Clock Setting	R/W	03h
43h~42h	Reserved		0s
44h	CLK-GEN 1 Command Byte 0	R/W	00h
45h	CLK-GEN 1 Command Byte 1	R/W	00h
46h	CLK-GEN 1 Command Byte 2	R/W	00h
47h	CLK-GEN 1 Command Byte 3	R/W	00h
48h	CLK-GEN 1 Read Data Byte 0	RO	00h
49h	CLK-GEN 1 Read Data Byte 1	RO	00h
4Ah	CLK-GEN 1 Read Data Byte 2	RO	00h
4Bh	CLK-GEN 1 Read Data Byte 3	RO	00h
4Fh~4Ch	Reserved		0s
50h	ICS 557 Clock Select Control Register	R/W	00h
Note : "*" means the value may be changed in the future FPGA FW update release.			

## 5.6.2 FPGA Configuration Registers Descriptions

Register Address : **SPI Base + 00h**

Register Name : **FPGA Device ID (Low Byte) Register**

Default Value: 05h

Attribute: Read Only

Bit	Description	Read/Write
7-0	FPGA Device ID (Low Byte) This offset 01h field combined with this field identifies the particular device. This identifier is allocated by the FPGA design team.	RO

Register Address : **SPI Base + 01h**

Register Name : **FPGA Device ID (High Byte) Register**

Default Value: 80h

Attribute: Read Only

Bit	Description	Read/Write
7-0	FPGA Device ID (High Byte) This field combined with the offset 00h field identifies the particular device. This identifier is allocated by the FPGA design team.	RO

Register Address : **SPI Base + 02h**



Register Name : **FPGA Revision ID (Low Byte) Register**

Default Value: \*\*

Attribute: Read Only

Bit	Description	Read/Write
7-0	FPGA Revision ID (Low Byte) This offset 03h register combined with this register specifies the FPGA device specific revision identifier. The value may be changed in the future FPGA FW update release.	RO

Register Address : **SPI Base + 03h**

Register Name : **FPGA Revision ID (High Byte) Register**

Default Value: 00h\*

Attribute: Read Only

Bit	Description	Read/Write
7-0	FPGA Revision ID (High Byte) This register combined with the offset 02h register specifies the FPGA device specific revision identifier. The value may be changed in the future FPGA FW update release.	RO

Register Address : **SPI Base + 04h**

Register Name : **BM GPI Status (07-00 Low Byte) Register**

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	BM GPIO 00: This bit reflects the state of the BM general purpose input signal GPIO 00 and writes will have no effect. 0: BM GPIO 00 state is low 1: BM GPIO 00 state is high	RO
1	BM GPIO 01: This bit reflects the state of the BM general purpose input signal GPIO 01 and writes will have no effect. 0: BM GPIO 01 state is low 1: BM GPIO 01 state is high	RO
2	BM GPIO 02: This bit reflects the state of the BM general purpose input signal GPIO 02 and writes will have no effect. 0: BM GPIO 02 state is low 1: BM GPIO 02 state is high	RO
3	BM GPIO 03: This bit reflects the state of the BM general purpose input signal GPIO 03 and writes will have no effect. 0: BM GPIO 03 state is low 1: BM GPIO 03 state is high	RO
4	BM GPIO 04: This bit reflects the state of the BM general purpose input signal GPIO 04 and writes will have no effect. 0: BM GPIO 04 state is low 1: BM GPIO 04 state is high	RO
5	BM GPIO 05: This bit reflects the state of the BM general purpose input signal GPIO 05 and writes will have no effect. 0: BM GPIO 05 state is low 1: BM GPIO 05 state is high	RO
6	BM GPIO 06: This bit reflects the state of the BM general purpose input signal GPIO 06 and writes will have no effect. 0: BM GPIO 06 state is low 1: BM GPIO 06 state is high	RO
7	BM GPIO 07: This bit reflects the state of the BM general purpose input signal GPIO 07 and writes will have no effect. 0: BM GPIO 07 state is low 1: BM GPIO 07 state is high	RO

Register Address : **SPI Base + 05h**

Register Name : **BM GPI (15-08 High Byte) Status Register**

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	BM GPIO 08: This bit reflects the state of the BM general purpose input signal GPIO 08 and writes will have no effect. 0: BM GPIO 08 state is low 1: BM GPIO 08 state is high	RO
1	BM GPIO 09: This bit reflects the state of the BM general purpose input signal GPIO 09 and writes will have no effect. 0: BM GPIO 09 state is low 1: BM GPIO 09 state is high	RO
2	BM GPIO 10: This bit reflects the state of the BM general purpose input signal GPIO 10 and writes will have no effect. 0: BM GPIO 10 state is low 1: BM GPIO 10 state is high	RO
3	BM GPIO 11: This bit reflects the state of the BM general purpose input signal GPIO 11 and writes will have no effect. 0: BM GPIO 11 state is low 1: BM GPIO 11 state is high	RO
4	BM GPIO 12: This bit reflects the state of the BM general purpose input signal GPIO 12 and writes will have no effect. 0: BM GPIO 12 state is low 1: BM GPIO 12 state is high	RO
5	BM GPIO 13: This bit reflects the state of the BM general purpose input signal GPIO 13 and writes will have no effect. 0: BM GPIO 13 state is low 1: BM GPIO 13 state is high	RO
6	BM GPIO 14: This bit reflects the state of the BM general purpose input signal GPIO 14 and writes will have no effect. 0: BM GPIO 14 state is low 1: BM GPIO 14 state is high	RO
7	BM GPIO 15: This bit reflects the state of the BM general purpose input signal GPIO 15 and writes will have no effect. 0: BM GPIO 15 state is low 1: BM GPIO 15 state is high	RO

Register Address : **SPI Base + 06h**

Register Name : **DSP GPI (07-00 Low Byte) Register**

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	DSP GPIO 00: This bit reflects the state of the DSP general purpose input signal GPIO 00 and writes will have no effect. 0: DSP GPIO 00 state is low 1: DSP GPIO 00 state is high	RO
1	DSP GPIO 01: This bit reflects the state of the DSP general purpose input signal GPIO 01 and writes will have no effect. 0: DSP GPIO 01 state is low 1: DSP GPIO 01 state is high	RO
2	DSP GPIO 02: This bit reflects the state of the DSP general purpose input signal GPIO 02 and writes will have no effect. 0: DSP GPIO 02 state is low 1: DSP GPIO 02 state is high	RO
3	DSP GPIO 03: This bit reflects the state of the DSP general purpose input signal GPIO 03 and writes will have no effect. 0: DSP GPIO 03 state is low 1: DSP GPIO 03 state is high	RO
4	DSP GPIO 04: This bit reflects the state of the DSP general purpose input signal GPIO 04 and writes will have no effect. 0: DSP GPIO 04 state is low 1: DSP GPIO 04 state is high	RO
5	DSP GPIO 05: This bit reflects the state of the DSP general purpose input signal GPIO 05 and writes will have no effect. 0: DSP GPIO 05 state is low 1: DSP GPIO 05 state is high	RO
6	DSP GPIO 06: This bit reflects the state of the DSP general purpose input signal GPIO 06 and writes will have no effect. 0: DSP GPIO 06 state is low 1: DSP GPIO 06 state is high	RO
7	DSP GPIO 07: This bit reflects the state of the DSP general purpose input signal GPIO 07 and writes will have no effect. 0: DSP GPIO 07 state is low 1: DSP GPIO 07 state is high	RO

Register Address : **SPI Base + 07h**

Register Name : **DSP GPI (15-08 High Byte) Status Register**

Default Value: 00h

Attribute: Read Only

Bit	Description	Read/Write
0	DSP GPIO 08: This bit reflects the state of the DSP general purpose input signal GPIO 08 and writes will have no effect. 0: DSP GPIO 08 state is low 1: DSP GPIO 08 state is high	RO
1	DSP GPIO 09: This bit reflects the state of the DSP general purpose input signal GPIO 09 and writes will have no effect. 0: DSP GPIO 09 state is low 1: DSP GPIO 09 state is high	RO
2	DSP GPIO 10: This bit reflects the state of the DSP general purpose input signal GPIO 10 and writes will have no effect. 0: DSP GPIO 10 state is low 1: DSP GPIO 10 state is high	RO
3	DSP GPIO 11: This bit reflects the state of the DSP general purpose input signal GPIO 11 and writes will have no effect. 0: DSP GPIO 11 state is low 1: DSP GPIO 11 state is high	RO
4	DSP GPIO 12: This bit reflects the state of the DSP general purpose input signal GPIO 12 and writes will have no effect. 0: DSP GPIO 12 state is low 1: DSP GPIO 12 state is high	RO
5	DSP GPIO 13: This bit reflects the state of the DSP general purpose input signal GPIO 13 and writes will have no effect. 0: DSP GPIO 13 state is low 1: DSP GPIO 13 state is high	RO
6	DSP GPIO 14: This bit reflects the state of the DSP general purpose input signal GPIO 14 and writes will have no effect. 0: DSP GPIO 14 state is low 1: DSP GPIO 14 state is high	RO
7	DSP GPIO 15: This bit reflects the state of the DSP general purpose input signal GPIO 15 and writes will have no effect. 0: DSP GPIO 15 state is low 1: DSP GPIO 15 state is high	RO

Register Address : **SPI Base + 08h**  
 Register Name : **Debug LED Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
0	DEBUG_LED 1: This bit can be updated by the DSP software to drive a high or low value on the debug LED 0 pin. 0: DEBUG_LED 1 drives low 1: DEBUG_LED 1 drives high	R/W
1	DEBUG_LED 2: This bit can be updated by the DSP software to drive a high or low value on the debug LED 1 pin. 0: DEBUG_LED 2 drives low 1: DEBUG_LED 2 drives high	R/W
2	DEBUG_LED 3: This bit can be updated by the DSP software to drive a high or low value on the debug LED 2 pin 0: DEBUG_LED 3 drives low 1: DEBUG_LED 3 drives high	R/W
3	DEBUG_LED 4: This bit can be updated by the DSP software to drive a high or low value on the debug LED 3 pin 0: DEBUG_LED 4 drives low 1: DEBUG_LED 4 drives high	R/W
7-4	Reserved	RO

Register Address : **SPI Base + 09h**

Register Name : **MMC Control Register**

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	MMC_DETECT#: This bit reflects the MMC_DETECT# state and it is used by the MMC to indicate the AMC chassis insertion status. 0: MMC_DETECT# state is low to indicate that the EVM is inserted into the AMC chassis. 1: MMC_DETECT# state is high to indicate that the EVM is not inserted into the AMC chassis.	RO
1	MMC_RESETSTAT#: This bit reflects the DSP RESETSTAT# state and the FPGA will drive the same logic value on the MMC_RESETSTAT# pin ( to MMC ). 0: DSP RESETSTAT# state is low and the FPGA drives MMC_RESETSTAT# low to MMC 1: DSP RESETSTAT# state is high and the FPGA drives MMC_RESETSTAT# high to MMC	RO
2	MMC_POR_IN_AMC#: This bit reflects the MMC_POR_IN_AMC# state and it is used by the MMC to trigger a Power-on sequence & reset event. 0: MMC_POR_IN_AMC# state is low to trigger a Power-on sequence & reset event. 1: MMC_POR_IN_AMC# state is high and the FPGA stays in current state.	RO
3	MMC_WR_AMC#: This bit reflects the MMC_WR_AMC# state and it is used by the MMC to trigger a warm reset event. 0: MMC_WR_AMC# state is low to trigger a warm reset event. 1: MMC_WR_AMC# state is high and the FPGA stays in current state	RO
4	MMC_BOOTCOMPLETE: This bit reflects the DSP_BOOTCOMPLETE state and the FPGA will drive the same logic value on the MMC_BOOTCOMPLETE pin ( to MMC ). 0: DSP_BOOTCOMPLETE state is low and the FPGA drives MMC_BOOTCOMPLETE low to MMC 1: DSP_BOOTCOMPLETE state is high and the FPGA drives MMC_BOOTCOMPLETE high to MMC	RO
7-5	Reserved	RO

Register Address : **SPI Base + 0Ah**

Register Name : **PHY Control Register**

Default Value: 03h

Attribute: Read/Write

<b>Bit</b>	<b>Description</b>	<b>Read/Write</b>
0	PHY_INT#: This bit reflects the PHY_INT# state. 0: PHY_INT# state is low. 1: PHY_INT# state is high.	RO
1	PHY_RST#: This bit can be updated by the DSP software to drive a high or low value on the PHY_RST# pin 0: PHY_RST# drives low 1: PHY_RST# drives high	R/W
7-3	Reserved	RO



Register Address : **SPI Base + 0Bh**

Register Name : **Reset Button Status Register**

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	FULL_RESET button status: This bit reflects the FULL_RESET button state. This button is used to request a power full reset sequence to DSP. A logic Low to High transition on this button signal will complete the FPGA FULL_RESET sequence with a specified delay time. 0: FULL_RESET button state is low 1: FULL_RESET button state is high	RO
1	WARM_RESET button status (RFU): This bit reflects the WARM_RESET button state. This button is used to request a warm reset sequence to DSP. A logic Low to High transition on this button signal will complete the FPGA WARM_RESET sequence with a specified delay time. 0: WARM_RESET button state is low 1: WARM_RESET button state is high	RO
2	COLD_RESET button status (RFU): This bit reflects the COLD_RESET button state. This button is used to request a hard reset sequence to DSP. A logic Low to High transition on this button signal will complete the FPGA HARD_RESET sequence with a specified delay time. 0: COLD_RESET button state is low 1: COLD_RESET button state is high	RO
3	Reserved	RO
4	DSP_RESETSTAT#: This bit reflects the DSP_RESETSTAT# state. 0: DSP_RESETSTAT# state is low 1: DSP_RESETSTAT# state is high	RO
5	TRGRSTZ: This bit reflects the TRGRSTZ state. 0: TRGRSTZ state is low 1: TRGRSTZ state is high	RO
6	PCIESSEN: This bit reflects the PCIESSEN switch state. 0: PCIESSEN state is low 1: PCIESSEN state is high	RO
7	User Defined Switch: This bit reflects the User_Define_Switch state. 0: User Defined Switch state is low 1: User Defined Switch state is high	RO

Register Address : **SPI Base + 0Ch**

Register Name : **Miscellaneous - 1 Register**

Default Value: 1Ch

Attribute: Read/Write

Bit	Description	Read/Write
1-0	Reserved	R/W
2	NAND_WP#: This bit can be updated by the DSP software to drive a high or low value on the NAND_WP# pin (RFU) 0: NAND_WP# drives low 1: NAND_WP# drives high	R/W
3	XDS560_IL Enable Control : 0: XDS560 mezzanine card is disabled. 1: XDS560 mezzanine card is enabled.	R/W
4	NOR_WP#: This bit can be updated by the DSP software to drive a high or low value on the NOR_WP# pin (RFU) 0: NOR_WP# drives low 1: NOR_WP# drives high	R/W
5	EEPROM_WP: This bit can be updated by the DSP software to drive a high or low value on the EEPROM_WP pin (RFU) 0: EEPROM_WP drives low 1: EEPROM_WP drives high	R/W
6	PCA9306_EN: This bit can be updated by the DSP software to drive a high or low value on the PCA9306_EN pin (RFU) 0: PCA9306_EN drives low 1: PCA9306_EN drives high	R/W
7	Reserved	RO

Register Address : **SPI Base + 0Dh**

Register Name : Miscellaneous - 2 Register

Default Value: ----

Attribute: Read Only

Bit	Description	Read/Write
0	FPGA FW Update SPI Interface Enable Status: This bit reflects the FPGA FW Update SPI Interface Enable status. The FPGA FW Update SPI interface could be enabled/disabled through the offset 0Eh register. 0: FPGA FW update SPI interface is disabled. 1: FPGA FW update SPI interface is enabled. The DSP_GPIO[12] is mapped to FPGA_FW_SPI_CLK. The DSP_GPIO[13] is mapped to FPGA_FW_SPI_CS#. The DSP_GPIO[14] is mapped to FPGA_FW_SPI_MOSI. The DSP_GPIO[15] is mapped to FPGA_FW_SPI_MISO.	RO
2	DSP_HOUT status: This bit reflects the DSP_HOUT signal state. 0: DSP_HOUT state is low 1: DSP_HOUT state is high	RO
3	DSP_SYSCLKOUT status: This bit reflects the DSP_SYSCLKOUT signal state. 0: DSP_SYSCLKOUT state is low 1: DSP_SYSCLKOUT state is high	RO
7-4	Reserved	RO

Register Address : **SPI Base + 0Eh**

Register Name : **FPGA FW Update SPI Interface Control Register**

Default Value: Default Value: ----

Attribute: Read/Write

Bit	Description	Read/Write
7-0	FPGA FW Update SPI Interface Enable Control: These bits are used to enable/disable the FPGA FW Update SPI Interface. If the value of this register be set to 68h, the FPGA FW Update SPI interface would be enabled. All the other values set to this register would disable the FPGA FW Update SPI interface. 68h: FPGA FW update SPI interface is enabled. Others: FPGA FW update SPI interface is disabled. The DSP_GPIO[12] is mapped to FPGA_FW_SPI_CLK. The DSP_GPIO[13] is mapped to FPGA_FW_SPI_CS#. The DSP_GPIO[14] is mapped to FPGA_FW_SPI_MOSI. The DSP_GPIO[15] is mapped to FPGA_FW_SPI_MISO.	R/W

Register Address : **SPI Base + 0Fh**  
 Register Name : **Scratch Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	Scratch Data	R/W

Register Address : **SPI Base + 10h**  
 Register Name : **CLK-GEN 2 Control Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
0	Initiate a data transfer via the SPI bus to update the SPI command to CDCE62005 Clock Generator #2 0: Idle state 1: Write 1 to perform the SPI command update process.	R/W
1	The BUSY status indication for the CDCE62005 Clock Generator #2 SPI bus 0: The SPI bus for the CDCE62005 Clock Generator #2 is idle. 1: The SPI bus for the CDCE62005 Clock Generator #2 is busy and a SPI command is processing..	RO
1	The BUSY status indication for the CDCE62005 Clock Generator 2 SPI bus 0 : The SPI bus for the CDCE62005 Clock Generator 2 is idle. 1 : The SPI bus for the CDCE62005 Clock Generator 2 is busy and a SPI command is processing..	RO
2	DSP_PORz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
3	DSP_RESETFULLz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
4	DSP_RESETr signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
7-5	Reserved	RO

Register Address : **SPI Base + 11h**  
 Register Name : **CLK-GEN 2 Interface Clock Setting Register**  
 Default Value: 03h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register is a clock divider setting to adjust the interface clock for the CDCE62005 Clock Generator #2 SPI bus. 00: CDCE62005 #2 SPI Clock = 12MHz ( = 48 / 4 ) 01: CDCE62005 #2 SPI Clock = 12MHz ( = 48 / 4 ) 02: CDCE62005 #2 SPI Clock = 8 MHz ( = 48 / 6 ) 03: CDCE62005 #2 SPI Clock = 6 MHz ( = 48 / 8 ) 04: CDCE62005 #2 SPI Clock = 4.8 MHz ( = 48 /10 ) 05: CDCE62005 #2 SPI Clock = 4 MHz ( = 48 /12 ) 06: CDCE62005 #2 SPI Clock = 3.42 MHz ( = 48 / 14 ) ..... X: CDCE62005 #2 SPI Clock = 48 MHz /((X+1)*2) if X != 0	R/W

Register Address : **SPI Base + 12h ~ 13h**  
 Register Name : **Reserved**

Register Address : **SPI Base + 14h**  
 Register Name : **CLK-GEN 2 Command Byte 0 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 0 to the CDCE62005 Clock Generator #2 3-0: SPI command address field bit 3 to bit 0 7-4: SPI command data field bit 3 to bit 0	R/W

Register Address : **SPI Base + 15h**  
 Register Name : **CLK-GEN 2 Command Byte 1 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 1 to the CDCE62005 Clock Generator #2 7-0: SPI command data field bit 11 to bit 4	R/W

Register Address : **SPI Base + 16h**  
 Register Name : **CLK-GEN 2 Command Byte 2 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 2 to the CDCE62005 Clock Generator #2 7-0: SPI command data field bit 19 to bit12	R/W

Register Address : **SPI Base + 17h**  
 Register Name : **CLK-GEN 2 Command Byte 3 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 3 to the CDCE62005 Clock Generator #2 7-0: SPI command data field bit 27 to bit 20	R/W

Register Address : **SPI Base + 18h**  
 Register Name : **CLK-GEN 2 Read Data Byte 0 Register**  
 Default Value: 00h  
 Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 0 from the CDCE62005 Clock Generator #2 for responding a host SPI Read Command. 3-0: The SPI read back register address [3-0] for a SPI Read Command 7-4: The SPI read back data bit 3 to bit 0 for a SPI Read Command.	RO

Register Address : **SPI Base + 19h**  
 Register Name : **CLK-GEN 2 Read Data Byte 1 Register**  
 Default Value: 00h  
 Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #2 for responding a host SPI Read Command. 7-0: The SPI read back data bit 11 to bit 4 for a SPI Read Command.	RO

Register Address : **SPI Base + 1Ah**

Register Name : **CLK-GEN 2 Read Data Byte 2 Register**

Default Value: 00h

Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #2 for responding a host SPI Read Command. 7-0: The SPI read back data bit 19 to bit 12 for a SPI Read Command.	RO

Register Address : **SPI Base + 1Bh**

Register Name : **CLK-GEN 2 Read Data Byte 3 Register**

Default Value: 00h

Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #2 for responding a host SPI Read Command. 7-0: The SPI read back data bit 27 to bit 20 for a SPI Read Command.	RO

Register Address : **SPI Base + 1Ch ~ 1Fh**

Register Name : **Reserved**

Register Address : **SPI Base + 20h**  
 Register Name : **CLK-GEN 3 Control Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
0	Initiate a data transfer via the SPI bus to update the SPI command to CDCE62005 Clock Generator #3 0: Idle state 1: Write 1 to perform the SPI command update process.	R/W
1	The BUSY status indication for the CDCE62005 Clock Generator #3 SPI bus 0: The SPI bus for the CDCE62005 Clock Generator #3 is idle. 1: The SPI bus for the CDCE62005 Clock Generator #3 is busy and a SPI command is processing.	RO
1	The BUSY status indication for the CDCE62005 Clock Generator 2 SPI bus 0 : The SPI bus for the CDCE62005 Clock Generator 2 is idle. 1 : The SPI bus for the CDCE62005 Clock Generator 2 is busy and a SPI command is processing..	RO
2	DSP_PORz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
3	DSP_RESETFULLz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
4	DSP_RESETr signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
7-5	Reserved	RO



Register Address : **SPI Base + 21h**

Register Name : **CLK-GEN 3 Interface Clock Setting Register**

Default Value: 00h

Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register is a clock divider setting to adjust the interface clock for the CDCE62005 Clock Generator #3 SPI bus. 00: CDCE62005 #3 SPI Clock = 12MHz ( = 48 / 4 ) 01: CDCE62005 #3 SPI Clock = 12MHz ( = 48 / 4 ) 02: CDCE62005 #3 SPI Clock = 8 MHz ( = 48 / 6 ) 03: CDCE62005 #3 SPI Clock = 6 MHz ( = 48 / 8 ) 04: CDCE62005 #3 SPI Clock = 4.8 MHz ( = 48 /10 ) 05: CDCE62005 #3 SPI Clock = 4 MHz ( = 48 /12 ) 06: CDCE62005 #3 SPI Clock = 3.42 MHz ( = 48 / 14 ) ..... X: CDCE62005 #3 SPI Clock = 48 MHz /((X+1)*2) if X != 0	R/W

Register Address : **SPI Base + 22h ~ 23h**

Register Name : **Reserved**

Register Address : **SPI Base + 24h**  
 Register Name : **CLK-GEN 3 Command Byte 0 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 0 to the CDCE62005 Clock Generator #3 3-0: SPI command address field bit 3 to bit 0 7-4: SPI command data field bit 3 to bit 0	R/W

Register Address : **SPI Base + 25h**  
 Register Name : **CLK-GEN 3 Command Byte 1 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 1 to the CDCE62005 Clock Generator #3 7-0: SPI command data field bit 11 to bit 4	R/W

Register Address : **SPI Base + 26h**  
 Register Name : **CLK-GEN 3 Command Byte 2 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 2 to the CDCE62005 Clock Generator #3 7-0: SPI command data field bit 19 to bit 12	R/W

Register Address : **SPI Base + 27h**  
 Register Name : **CLK-GEN 3 Command Byte 3 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 3 to the CDCE62005 Clock Generator #3 7-0: SPI command data field bit 27 to bit 20	R/W

Register Address : **SPI Base + 28h**

Register Name : **CLK-GEN 3 Read Data Byte 0 Register**

Default Value: 00h

Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 0 from the CDCE62005 Clock Generator #3 for responding to a host SPI Read Command. 3-0: The SPI read back register address [3-0] for a SPI Read Command 7-4: The SPI read back data bit 3 to bit 0 for a SPI Read Command.	RO

Register Address : **SPI Base + 29h**

Register Name : **CLK-GEN 3 Read Data Byte 1 Register**

Default Value: 00h

Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #3 for responding to a host SPI Read Command. 7-0: The SPI read back data bit 11 to bit 4 for a SPI Read Command.	RO

Register Address : **SPI Base + 2Ah**

Register Name : **CLK-GEN 3 Read Data Byte 2 Register**

Default Value: 00h

Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #3 for responding to a host SPI Read Command. 7-0: The SPI read back data bit 19 to bit 12 for a SPI Read Command.	RO

Register Address : **SPI Base + 2Bh**

Register Name : **CLK-GEN 3 Read Data Byte 3 Register**

Default Value: 00h

Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62005 Clock Generator #3 for responding to a host SPI Read Command. 7-0: The SPI read back data bit 27 to bit 20 for a SPI Read Command.	RO

Register Address : **SPI Base + 2Ch ~ 2Fh**

Register Name : **Reserved**

Register Address : **SPI Base + 30h ~ 3Fh(RFU)**

Register Name : **PM Bus Control Register**

Default Value: 00h

Attribute: Read/Write

Bit	Description	Read/Write
7-0	RFU	R/W

Register Address : **SPI Base + 40h**  
 Register Name : **CLK-GEN 1 Control Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
0	Initiate a data transfer via the SPI bus to update the SPI command to CDCE62002 Clock Generator #1 0: Idle state 1: Write 1 to perform the SPI command update process.	R/W
1	The BUSY status indication for the CDCE62002 Clock Generator #1 SPI bus 0: The SPI bus for the CDCE62002 Clock Generator #1 is idle. 1: The SPI bus for the CDCE62002 Clock Generator #1 is busy and a SPI command is processing..	RO
1	The BUSY status indication for the CDCE62005 Clock Generator 2 SPI bus 0 : The SPI bus for the CDCE62005 Clock Generator 2 is idle. 1 : The SPI bus for the CDCE62005 Clock Generator 2 is busy and a SPI command is processing..	RO
2	DSP_PORz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
3	DSP_RESETFULLz signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
4	DSP_RESETr signal will generate one active pulse after data transfer sequence is finished 1: Enable 0: Disable	R/W
7-5	Reserved	RO

Register Address : **SPI Base + 41h**  
 Register Name : **CLK-GEN 1 Interface Clock Setting Register**  
 Default Value: 03h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register is a clock divider setting to adjust the interface clock for the CDCE62002 Clock Generator #1 SPI bus. 00: CDCE62002 SPI Clock = 12MHz ( = 48 / 4 ) 01: CDCE62002 SPI Clock = 12MHz ( = 48 / 4 ) 02: CDCE62002 SPI Clock = 8 MHz ( = 48 / 6 ) 03: CDCE62002 SPI Clock = 6 MHz ( = 48 / 8 ) 04: CDCE62002 SPI Clock = 4.8 MHz ( = 48 /10 ) 05: CDCE62002 SPI Clock = 4 MHz ( = 48 /12 ) 06: CDCE62002 SPI Clock = 3.42 MHz ( = 48 / 14) ..... X: CDCE62002 SPI Clock = 48 MHz /((X+1)*2) if X != 0	R/W

Register Address : **SPI Base + 42h ~ 43h**  
 Register Name : **Reserved**

Register Address : **SPI Base + 44h**  
 Register Name : **CLK-GEN 1 Command Byte 0 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 0 to the CDCE62002 Clock Generator #1 3-0: SPI command address field bit 3 to bit 0 7-4: SPI command data field bit 3 to bit 0	R/W

Register Address : **SPI Base + 45h**  
 Register Name : **CLK-GEN 1 Command Byte 1 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 1 to the CDCE62002 Clock Generator #1 7-0: SPI command data field bit 11 to bit 4	R/W

Register Address : **SPI Base + 46h**  
 Register Name : **CLK-GEN 1 Command Byte 2 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 2 to the CDCE62002 Clock Generator #1 7-0: SPI command data field bit 19 to bit12	R/W

Register Address : **SPI Base + 47h**  
 Register Name : **CLK-GEN 1 Command Byte 3 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register specifies the update SPI command byte 3 to the CDCE62002 Clock Generator #1 7-0: SPI command data field bit 27 to bit 20	R/W

Register Address : **SPI Base + 48h**  
 Register Name : **CLK-GEN 1 Read Data Byte 0 Register**  
 Default Value: 00h  
 Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 0 from the CDCE62002 Clock Generator #1 for responding a host SPI Read Command. 3-0: The SPI read back register address [3-0] for a SPI Read Command 7-4: The SPI read back data bit 3 to bit 0 for a SPI Read Command.	RO

Register Address : **SPI Base + 49h**  
 Register Name : **CLK-GEN 1 Read Data Byte 1 Register**  
 Default Value: 00h  
 Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62002 Clock Generator #1 for responding a host SPI Read Command. 7-0: The SPI read back data bit 11 to bit 4 for a SPI Read Command.	RO

Register Address : **SPI Base + 4Ah**  
 Register Name : **CLK-GEN 1 Read Data Byte 2 Register**  
 Default Value: 00h  
 Attribute: Read Only

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62002 Clock Generator #1 for responding a host SPI Read Command. 7-0: The SPI read back data bit 19 to bit 12 for a SPI Read Command.	RO

Register Address : **SPI Base + 4Bh**  
 Register Name : **CLK-GEN 1 Read Data Byte 3 Register**  
 Default Value: 00h  
 Attribute: Read/Write

Bit	Description	Read/Write
7-0	This register reflects the read back data byte 1 from the CDCE62002 Clock Generator #1 for responding a host SPI Read Command. 7-0: The SPI read back data bit 27 to bit 20 for a SPI Read Command.	RO

Register Address : **SPI Base + 4Ch ~ 4Fh**  
 Register Name : **Reserved**

Register Address : **SPI Base + 50h**  
 Register Name : **ICS 557 Clock Selection Control Register**  
 Default Value: 00h  
 Attribute : Read/Write

Bit	Description	Read/Write
0	FPGA_IC557_SEL : This bit can be updated by the DSP software to drive a high or low value on the FPGA_IC557_SEL pin. FPGA will latch the BM_GPIO7 as the default value when power-sequence is finished. 0 : FPGA_IC557_SEL drives low 1 : FPGA_IC557_SEL drives high	R/W
7-1	Reserved	RO



## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI.

Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements. Following are URLs where you can obtain information on other

Texas Instruments products and application solutions:

### Product Applications

Amplifiers [amplifier.ti.com](http://amplifier.ti.com)

Data Converters [dataconverter.ti.com](http://dataconverter.ti.com)

DSP [dsp.ti.com](http://dsp.ti.com)

Clocks and Timers [www.ti.com/clocks](http://www.ti.com/clocks)

Interface [interface.ti.com](http://interface.ti.com)

Logic [logic.ti.com](http://logic.ti.com)

Power Mgmt [power.ti.com](http://power.ti.com)

Microcontrollers [microcontroller.ti.com](http://microcontroller.ti.com)

RFID [www.ti-rfid.com](http://www.ti-rfid.com)

RF/IF and ZigBee® Solutions [www.ti.com/lprf](http://www.ti.com/lprf)

Audio [www.ti.com/audio](http://www.ti.com/audio)

Automotive [www.ti.com/automotive](http://www.ti.com/automotive)

Broadband [www.ti.com/broadband](http://www.ti.com/broadband)

Digital Control [www.ti.com/digitalcontrol](http://www.ti.com/digitalcontrol)

Medical [www.ti.com/medical](http://www.ti.com/medical)

Military [www.ti.com/military](http://www.ti.com/military)

Optical Networking [www.ti.com/opticalnetwork](http://www.ti.com/opticalnetwork)

Security [www.ti.com/security](http://www.ti.com/security)

Telephony [www.ti.com/telephony](http://www.ti.com/telephony)

Video & Imaging [www.ti.com/video](http://www.ti.com/video)

Wireless [www.ti.com/wireless](http://www.ti.com/wireless)

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2011, Texas Instruments Incorporated